



本社：〒160-8366

東京都新宿区西新宿 6 丁目 24 番 1 号
西新宿三井ビルディング

報告書番号：PCN#20120612001A
2012 年 10 月 22 日

お客様各位

日本テキサス・インスツルメンツ株式会社
営業・技術本部 カスタマドキュメント
マネージャ 牧 達郎 (牧)

TI-Mexico/TI-Malaysia/TI-Taiwan サイト製造 一部製品 モールド樹脂変更のご案内

(既報 4015 製品からの対象除外 2 製品の連絡)

(初版 PCN20120612001 2012 年 6 月 15 日発行)

拝啓 貴社益々ご清栄の事とお喜び申し上げます。平素は弊社製品のご愛顧を賜り、厚く御礼申し上げます。さて、標題の件につきましてご連絡させていただきます。ご査収の程、宜しくお願い申し上げます。

今回のお知らせは、変更実施についての追加連絡になります。変更の詳細は、次頁以降をご参照下さい。

お客様におかれましては、本通知発行日後、**30 日以内**に通知確認のご連絡をお願いいたします。また、30 日以内にご連絡が無い場合には、本変更をご承認いただけたものと判断させていただきます。変更品評価用サンプルもしくは追加データご入用の場合には、本通知発行日後 30 日以内にご依頼をお願いいたします。

変更品の出荷につきましては、お客様との早期変更実施の個別契約を締結している場合を除いては、本通知発行日より **90 日**以降に予定いたしております。この通知期間は、弊社品質標準に基づいております。

本通知は、いかなる製品の製造終了に関する状況を変更するものではありません。既に製造終了の連絡をさせていただいている場合には、本通知によって、既通知の最終受注日及び最終出荷日が延長されることはありません。

本通知は、通知日前 24 ヶ月以内に本変更対象製品をご購入いただいたお客様に連絡させていただいております。

尚、変更時期につきましては、在庫状況により異なりますので、担当営業にお問い合わせ下さい。また、ご不明な点、ご質問等がございましたら、担当営業或いは pcn_tij@list.ti.com にお問い合わせ下さい。

以上

変更概要

通知タイプ	☐ Initial notice (Plan)		☒ Final notice	
変更概要	Design/Specification	☐ Design	☐ Electrical	☐ Mechanical
	Wafer Fab	☐ Site	☐ Process	☐ Material
	Wafer Bump	☐ Site	☐ Process	☐ Material
	☒ Assembly	☐ Site	☐ Process	☒ Material
	Test	☐ Site	☐ Process	
	Others	☐ Packing/Shipping/Labeling		☐ -
変更内容	下記変更について既報 4015 製品からの対象除外 2 製品の連絡になります。 TI-Mexico/TI-Malaysia/TI-Taiwan サイト製造 一部製品 モールド樹脂変更 現行 : 部材型番: 4205694 変更後: 部材型番: 4211880			
対象製品	対象製品リスト参照			
変更時期	—			
品質認定試験	☒ 計画		☐ 終了	
製品表示	☒ 変更無し		☐ 変更あり	
備考	—			

変更内容

内容：今回のお知らせは、下記変更について既報4015製品からの対象除外2製品の連絡になります。
 TI-Mexico(メキシコ)/TI-Malaysia(マレーシア)/TI-Taiwan(台湾) サイト製造 一部製品について、現
 行 部材型番:4205694 モールド樹脂を使用して製造しておりますが、供給能力確保の為に、これに替
 えて、部材型番:4211880 モールド樹脂に変更します。組立サイトの変更はありません。
 尚、今回の変更で、製品についての互換性(寸法/公差), 外観, 動作特性, 品質, 信頼性への影響はありません。

変更内容	現行	変更後
モールド樹脂(部材型番)	4205694	4211880

理由：供給能力確保の為

詳細：

TI-Mexico サイトにおける部材型番:4211880 モールド樹脂を使用した SOIC パッケージ製品の製造
 は認定されています。下記信頼性試験結果(2011 年 10 月 17 日終了)を参照ください。

対象製品リスト

対象製品名				
☐ : 既報対象品 取消線 : 対象除外品				
74AC11000NS	SN65HVD1176DG4	SN74AS32DB	SN74LS629NS	TL494CNS
74AC11000NSR	SN65HVD1176DR	SN74AS32NS	SN74LS640-1NS	TL494CNSR
74AC11008NSR	SN65HVD11D	SN74AS32NSR	SN74LS640-1NSR	TL494CNSRG4
74AC11032NSR	SN65HVD11DR	SN74AS373NS	SN74LS640DB	TL497ACNS
74AC11138NSR	SN65HVD11DRG4	SN74AS373NSR	SN74LS640DBR	TL497ACNSR
74AC16244DL	SN65HVD11QD	SN74AS374NS	SN74LS640NS	TL499ACPS
74AC16245DL	SN65HVD12D	SN74AS374NSR	SN74LS640NSR	TL499ACPSR
74AC16373DL	SN65HVD12DG4	SN74AS638ANSR	SN74LS641NS	TL5001CPS
74ACT11244DBR	SN65HVD12DR	SN74AS640NS	SN74LS641NSR	TL5001CPSG4
74ACT11244NS	SN65HVD1780D	SN74AS640NSR	SN74LS641NSRG4	TL5001CPS-P
74ACT11245NS	SN65HVD1780DR	SN74AS74ADBR	SN74LS642NS	TL5001CPSR
74ACT11245NSR	SN65HVD1781D	SN74AS74ANS	SN74LS642NSG4	TL5001CPSR/1G4
74ACT11373NS	SN65HVD1781DG4	SN74AS74ANSR	SN74LS642NSR	TL5001CPSRG4
74ACT16240DL	SN65HVD1781DR	SN74AS760NS	SN74LS645-1NS	TL5001IPSR
74ACT16240DLR	SN65HVD1782D	SN74AS760NSR	SN74LS645-1NSR	TL592BPS

日本テキサス・インスツルメンツ株式会社

74ACT16244DL	SN65HVD1782DR	SN74AS86ANS	SN74LS645NS	TL592BPSR
74ACT16244DLR	SN65HVD1785D	SN74BCT125AD	SN74LS645NSR	TL592PS
74ACT16245DL	SN65HVD1785DR	SN74BCT125ADR	SN74LS670NS	TL592PSR
74ACT16245DLR	SN65HVD1786D	SN74BCT125ANS	SN74LS670NSR	TL594CDB
74ACT16373DL	SN65HVD1786DR	SN74BCT125ANSR	SN74LS682DB	TL594CNS
74ACT16373DLR	SN65HVD1787DR	SN74BCT126ANS	SN74LS682NS	TL594CNSR
74ACT16374DL	SN65HVD1791D	SN74BCT2244DB	SN74LS682NSR	TL594INSR
74ACT16374DLR	SN65HVD1791DR	SN74BCT2244NS	SN74LS684NSR	TL712CPS
74ACT16543DL	SN65HVD1792D	SN74BCT2244NSR	SN74LS688DBR	TL712CPSR
74ACT16652DL	SN65HVD1793D	SN74BCT2245NS	SN74LS688NS	TL7700CPS
74ACT16823DL	SN65HVD179D	SN74BCT2245NSR	SN74LS688NSR	TL7700CPSR
74ACT16827DL	SN65HVD20D	SN74BCT240DB	SN74LS73ANS	TL7705ACPS
ADS1251U	SN65HVD20DR	SN74BCT240NS	SN74LS74ADB	TL7705ACPSG4
ADS1251U/2K5	SN65HVD21D	SN74BCT240NSR	SN74LS74ADBR	TL7705ACPSR
ADS1251U/2K5G4	SN65HVD21DR	SN74BCT241NSR	SN74LS74ANS	TL7705CPS-B
ADS1251UG4	SN65HVD22D	SN74BCT244DB	SN74LS74ANSR	TL7705CPSR-B
ADS1252U	SN65HVD22DR	SN74BCT244NS	SN74LS74ANSRG4	TL7759CPS
ADS1252U/2K5	SN65HVD23D	SN74BCT244NSR	SN74LS75NSR	TL7759CPSR
ADS1252U/2K5G4	SN65HVD23DR	SN74BCT245DB	SN74LS85NS	TLC074AID
ADS1252UG4	SN65HVD23DRG4	SN74BCT245DBR	SN74LS85NSR	TLC074ID
ADS1253E	SN65HVD251D	SN74BCT245NS	SN74LS86ANS	TLC074IDR
ADS1253E/2K5	SN65HVD251DG4	SN74BCT245NSR	SN74LS86ANSR	TLC0820ACDBR
ADS1254E	SN65HVD251DR	SN74BCT25244DBR	SN74LS86ANSRG4	TLC0831CDR
ADS1255IDBR	SN65HVD251DRG4	SN74BCT2827CNS	SN74LS90NSR	TLC0831ID
ADS1255IDBT	SN65HVD252D	SN74BCT29827BNS	SN74LS92NS	TLC0831IDRG4
ADS1255IDBTG4	SN65HVD252DR	SN74BCT29843NS	SN74LS92NSR	TLC0832CD
ADS1256IDBR	SN65HVD3086ED	SN74BCT373NS	SN74LS93NS	TLC0832CDR
ADS1256IDBRG4	SN65HVD3086EDR	SN74BCT373NSR	SN74LS93NSE4	TLC0834CDR
ADS1256IDBT	SN65HVD30D	SN74BCT374DB	SN74LS93NSR	TLC0834CDRG4
ADS7816U	SN65HVD30DG4	SN74BCT374DBR	SN74LV00ADBR	TLC0834ID
ADS7816U/2K5	SN65HVD30DR	SN74BCT374NSR	SN74LV00ANS	TLC1078CD
ADS7816U/2K5G4	SN65HVD30DRG4	SN74BCT540ANS	SN74LV00ANSR	TLC1078CDR
ADS7816UB	SN65HVD31D	SN74BCT540ANSR	SN74LV02ADBR	TLC1078IDR
ADS7816UB/2K5	SN65HVD31DR	SN74BCT541ADB	SN74LV02ANS	TLC1079CD
ADS7816UB/2K5G4	SN65HVD32D	SN74BCT541ADBR	SN74LV02ANSR	TLC1079CDR
ADS7816UC	SN65HVD32DR	SN74BCT541ANS	SN74LV04ADB	TLC1079CNS
ADS7816UC/2K5	SN65HVD33D	SN74BCT541ANSR	SN74LV04ADBR	TLC14CD
ADS7816UC/2K5G4	SN65HVD33DR	SN74BCT573NS	SN74LV04ADR	TLC1543CDB
ADS7816UG4	SN65HVD34D	SN74BCT574DB	SN74LV04ANS	TLC1543CDBR
ADS7817U/2K5	SN65HVD34DR	SN74BCT574NS	SN74LV04ANSR	TLC1543CDBRG4
ADS7817U/2K5G4	SN65HVD35D	SN74BCT623NS	SN74LV05ADB	TLC1543IDB
ADS7822U	SN65HVD35DR	SN74BCT623NSR	SN74LV05ANS	TLC1543IDBR
ADS7822U/2K5	SN65HVD379DR	SN74BCT640NS	SN74LV05ANSR	TLC1543IDBRG4
ADS7822U/2K5G4	SN65HVD50D	SN74BCT640NSR	SN74LV06ADBR	TLC1549CD
ADS7822UB	SN65HVD52D	SN74BCT757DB	SN74LV06ANS	TLC1549CDR
ADS7822UB/2K5	SN65HVD52D-P	SN74BCT757NSR	SN74LV06ANSR	TLC2201ACD
ADS7822UC	SN65HVD52DR	SN74BCT760NSR	SN74LV07ADBR	TLC2201AID
ADS7822UC/2K5	SN65HVD53D	SN74CB3Q16210DL	SN74LV07ADR	TLC2201CDR
ADS7822UG4	SN65HVD53DG4	SN74CB3Q3245DBQR	SN74LV07ANS	TLC2201ID
ADS7841E	SN65HVD54D	SN74CB3Q3253DBQR	SN74LV07ANSR	TLC2202ACDR
ADS7841E/2K5	SN65HVD55D	SN74CB3T16211DL	SN74LV08AD	TLC2202CD
ADS7841E/2K5G4	SN65HVD55DR	SN74CB3T3245DBQR	SN74LV08ADBR	TLC2202CPS
ADS7841EB	SN65LBC170DB	SN74CBT16209ADL	SN74LV08ADR	TLC2202CPSR
ADS7841EG4	SN65LBC173D	SN74CBT16209ADLR	SN74LV08ANS	TLC2272CPS
ADS7842E	SN65LBC173DR	SN74CBT16210DL	SN74LV08ANS-P	TLC2272CPSG4
ADS7842E/1K	SN65LBC175D	SN74CBT16211ADL	SN74LV08ANSR	TLC2272CPSR
ADS7842EB	SN65LBC175DR	SN74CBT16211ADLR	SN74LV10ANSR	TLC2274CNS

日本テキサス・インスツルメンツ株式会社

ADS7842EB/1K	SN65LBC176D	SN74CBT16214CDLR	SN74LV11ADBR	TLC2274CNSG4
ADS7842EG4	SN65LBC176DG4	SN74CBT16214DLR	SN74LV11ANSR	TLC2274CNSR
ADS7843E	SN65LBC176DR	SN74CBT16233DLR	SN74LV123AD	TLC2274CNSRG4
ADS7843E/2K5	SN65LBC176DRG4	SN74CBT16245DLR	SN74LV123ADBR	TLC252CPS
ADS7843E/2K5G4	SN65LBC179D	SN74CBT3245CDBQR	SN74LV123ANS	TLC2543CDB
ADS7844E	SN65LBC179DR	SN74CBT3257CDR	SN74LV123ANSR	TLC2543CDBR
ADS7844E/2K5	SN65LBC179DRG4	SN74CBT3306DR	SN74LV125ADBR	TLC25551D
ADS7844E/2K5G4	SN65LBC180D	SN74CBTD16210DL	SN74LV125ANS	TLC25L2CPSR
ADS7844EB	SN65LBC180DG4	SN74CBTD16210DLG4	SN74LV125ANSR	TLC2652C-8D
ADS7844EB/2K5	SN65LBC180DR	SN74CBTD16210DLR	SN74LV125ATNSR	TLC2652C-8DR
ADS7844EB/2K5G4	SN65LBC180DRG4	SN74CBTD16211DL	SN74LV126ADBR	TLC271ACPS
ADS7844EG4	SN65LBC182D	SN74CBTD16211DLR	SN74LV126ANS	TLC271ACPSR
ADS7844N	SN65LBC182DR	SN74CBTLV16210DL	SN74LV126ANSR	TLC271BCPS
ADS7844N/1K	SN65LBC184D	SN74CBTLV16210DLR	SN74LV132ANS	TLC271CD
ADS7844N/1KG4	SN65LBC184DG4	SN74CBTLV16211DL	SN74LV132ANSR	TLC271CDR
ADS7844NB	SN65LBC184DR	SN74CBTLV16211DLR	SN74LV138AD	TLC271CDRG4
ADS7844NB/1K	SN65LBC184DRG4	SN74CBTLV16212DL	SN74LV138ADBR	TLC271CPS
ADS7844NB/1KG4	SN65LV1021DB	SN74CBTLV16212DLR	SN74LV138ADR	TLC271CPSR
ADS7845E	SN65LV1021DBR	SN74CBTLV16292DL	SN74LV138ANS	TLC271CPSRG4
ADS7846E	SN65LV1023ADB	SN74CBTLV16800DLR	SN74LV138ANS-P	TLC2711D
ADS7846E/2K5G4	SN65LV1023ADBR	SN74CBTLV3125DBQR	SN74LV138ANSR	TLC2711DR
ADS7846EG4	SN65LV1224BDB	SN74CBTLV3251DBQR	SN74LV139ANS	TLC272ACDR
ADS7863IDBQ	SN65LV1224BDBR	SN74CBTLV3251DR	SN74LV139ANSR	TLC272A1D
ADS8505IBDB	SN65LVCP22D	SN74CBTLV3253DBQR	SN74LV14ADB	TLC272BCDR
ADS8505IBDBG4	SN65LVCP23D	SN74CBTLV3253DR	SN74LV14ADBR	TLC272BCPS
ADS8505IBDBR	SN65LVDM050D	SN74CBTLV3257D	SN74LV14ANS	TLC272B1D
ADS8505IDB	SN65LVDM051D	SN74CBTLV3384DBQR	SN74LV14ANS-P	TLC272CD
ADS8509IBDB	SN65LVDM051DR	SN74CBTS16211DLR	SN74LV14ANSR	TLC272CDR
ADS8509IDB	SN65LVDM176D	SN74F00NS	SN74LV157ANS	TLC272CDRG4
ADS8509IDBR	SN65LVDM176DR	SN74F00NSR	SN74LV157ANSR	TLC272CPS
ADS8515IDB	SN65LVDM179D	SN74F02NS	SN74LV161ANSR	TLC272CPSG4
ADS8515IDBR	SN65LVDM179DR	SN74F02NSR	SN74LV163ANSR	TLC272CPSR
ADS8519IBDB	SN65LVDM180D	SN74F04DB	SN74LV164ANS	TLC272CPSRG4
ADS8519IBDBG4	SN65LVDM180DR	SN74F04NS	SN74LV164ANSR	TLC2721D
ADS8519IDB	SN65LVDM31D	SN74F04NSR	SN74LV165AD	TLC2721DR
ADS8519IDBR	SN65LVDM31DR	SN74F08DB	SN74LV165ADBR	TLC274A1D
ADS900E	SN65LVDS047D	SN74F08NS	SN74LV165ADR	TLC274BCNS
ADS900E/1KG4	SN65LVDS047DR	SN74F08NSR	SN74LV165ADRG4	TLC274B1D
ADS901E	SN65LVDS047DRG4	SN74F10NS	SN74LV165ANS	TLC274B1DR
ADS931E/1K	SN65LVDS048AD	SN74F10NSR	SN74LV165ANSR	TLC274B1DRG4
ADS931E/1KG4	SN65LVDS048ADR	SN74F112NS	SN74LV166ANSR	TLC274CD
AFE1230E	SN65LVDS051D	SN74F112NSR	SN74LV174ANSR	TLC274CDB
AM26C31CDB	SN65LVDS100D	SN74F11NSR	SN74LV175ANSR	TLC274CDBG4
AM26C31CDBR	SN65LVDS101D	SN74F125DB	SN74LV20ANS	TLC274CDR
AM26C31CNS	SN65LVDS104D	SN74F125NS	SN74LV20ANSR	TLC274CNS
AM26C31CNS-P	SN65LVDS104DG4	SN74F125NSR	SN74LV21ANSR	TLC274CNSR
AM26C31CNSR	SN65LVDS104DR	SN74F126NS	SN74LV221ADR	TLC2741DR
AM26C31IDB	SN65LVDS105D	SN74F138NS	SN74LV221ANS	TLC277CPS
AM26C31IDBG4	SN65LVDS122D	SN74F138NSR	SN74LV221ANSR	TLC277CPSR
AM26C31IDBR	SN65LVDS179D	SN74F151BNS	SN74LV240ADB	TLC2771DR
AM26C31INS	SN65LVDS179DR	SN74F151BNSR	SN74LV240ADBR	TLC2791D
AM26C31INSR	SN65LVDS180D	SN74F153NSR	SN74LV240ANS	TLC27L2ACPS
AM26C31INSR-B	SN65LVDS180DR	SN74F157ANS	SN74LV240ANSR	TLC27L2ACPSG4
AM26C32CDB	SN65LVDS1D	SN74F157ANSR	SN74LV244ADB	TLC27L2B1DR
AM26C32CDBR	SN65LVDS1DR	SN74F161ANS	SN74LV244ADBR	TLC27L2CD
AM26C32CNS	SN65LVDS2D	SN74F161ANSR	SN74LV244ANS	TLC27L2CDR
AM26C32CNS-P	SN65LVDS2DR	SN74F163ANS	SN74LV244ANSR	TLC27L2CPS

日本テキサス・インスツルメンツ株式会社

AM26C32CNSR	SN65LVDS2DRG4	SN74F174ANS	SN74LV244ATNSR	TLC27L2CPSR
AM26C32CNSRG4	SN65LVDS31D	SN74F175NS	SN74LV245ADB	TLC27L21D
AM26C321DB	SN65LVDS31DR	SN74F175NSR	SN74LV245ADBR	TLC27L21DR
AM26C321DBR	SN65LVDS31NS	SN74F20NS	SN74LV245ANS	TLC27L4A1DR
AM26C321NS	SN65LVDS31NSR	SN74F20NSR	SN74LV245ANSR	TLC27L4BCNS
AM26C321NSR	SN65LVDS32BD	SN74F240NS	SN74LV245ATDBR	TLC27L4B1DR
AM26LS31CDB	SN65LVDS32BDG4	SN74F240NSR	SN74LV273ADBR	TLC27L4CDR
AM26LS31CDBR	SN65LVDS32D	SN74F241NS	SN74LV273ANS	TLC27L4CNS
AM26LS31CNS	SN65LVDS32DR	SN74F241NSR	SN74LV273ANS-P	TLC27L4CNSR
AM26LS31CNS-H	SN65LVDS32NS	SN74F244DB	SN74LV273ANSR	TLC27L7CDR
AM26LS31CNSR	SN65LVDS32NSR	SN74F244DBR	SN74LV273ANSR	TLC27L7CPS
AM26LS32ACDB	SN65LVDS33D	SN74F244NS	SN74LV32AD	TLC27L7CPSR
AM26LS32ACDBR	SN65LVDS33DR	SN74F244NSR	SN74LV32ANS	TLC27L71D
AM26LS32ACNS	SN65LVDS33DRG4	SN74F245DB	SN74LV32ANS-P	TLC27L9CNS
AM26LS32ACNSR	SN65LVDS3486D	SN74F245NS	SN74LV32ANSR	TLC27L9CNSR
AM26LS32ACNSRG4	SN65LVDS3486DR	SN74F245NSR	SN74LV367ANSR	TLC27M2CD
AM26LV31CNS	SN65LVDS3487D	SN74F253NS	SN74LV373ANS	TLC27M2CPS
AM26LV31CNS-P	SN65LVDS3487DR	SN74F257NSR	SN74LV373ANSR	TLC27M2CPSR
AM26LV31CNSR	SN65LVDS34D	SN74F27NS	SN74LV374ANS	TLC27M2CPSRG4
AM26LV31E1NSR	SN65LVDS34DR	SN74F27NSR	SN74LV374ANSR	TLC27M4CD
AM26LV31INS	SN65LVDS391D	SN74F280BNS	SN74LV393ANS	TLC27M4CDR
AM26LV31INSR	SN65LVDS391DG4	SN74F280BNSR	SN74LV393ANSR	TLC27M4CNS
AM26LV32CNS	SN65LVDS9637BD	SN74F283NS	SN74LV4040ANSR	TLC27M4CNSR
AM26LV32CNS-P	SN65LVDS9637D	SN74F299NS	SN74LV4046AD	TLC27M7CD
AM26LV32CNSR	SN65LVDS9637DG4	SN74F30NS	SN74LV4046ADR	TLC27M7CDR
AM26LV32E1NSR	SN65LVDS9637DR	SN74F30NSR	SN74LV4046ADRG4	TLC27M7CPS
AM26LV32INS	SN65LVDS9638D	SN74F32DB	SN74LV4046ANS	TLC27M7CPSR
AM26LV32INSR	SN65LVDS9638DR	SN74F32DBR	SN74LV4046ANSR	TLC320AD77CDB
AMC6821SDBQ	SN65LVDS9638DRG4	SN74F32NS	SN74LV4051AD	TLC339CD
BQ2000SN-B5	SN65LVD100D	SN74F32NSR	SN74LV4051ANS	TLC339CDR
BQ2000SN-B5TR	SN65LVD132BD	SN74F373DB	SN74LV4051ANSR	TLC339CNS
BQ2002CSNG4	SN65LVD133D	SN74F373NS	SN74LV4052ANS	TLC339CNSR
BQ2002CSNTRG4	SN65LVD13486BDR	SN74F373NSR	SN74LV4052ANSR	TLC3391DR
BQ2002DSNG4	SN65LVD134D	SN74F374DB	SN74LV4053AD	TLC3521DR
BQ2002DSNTRG4	SN65LVD1390D	SN74F374DBR	SN74LV4053ADR	TLC35411DRG4
BQ2002ESN	SN65MLVDO47AD	SN74F374NS	SN74LV4053ANSR	TLC35451D
BQ2002GSNTR	SN65MLVDO47ADR	SN74F374NSR	SN74LV4066ADBR	TLC3702CD
BQ2002SN	SN65MLVDO47DR	SN74F38DB	SN74LV4066ADR	TLC3702CDG4
BQ2002SN-M01TR	SN65MLVD200AD	SN74F38DBR	SN74LV4066ANS	TLC3702CDR
BQ2002SN-SANTRG4	SN65MLVD200ADR	SN74F38NS	SN74LV4066ANSR	TLC3702CPS
BQ2002TSNTR	SN65MLVD200D	SN74F38NSR	SN74LV540ADB	TLC3702CPSR
BQ2004ESN	SN65MLVD201D	SN74F521NS	SN74LV540ADBR	TLC3702CPSRG4
BQ2004HSNG4	SN65MLVD204AD	SN74F521NSR	SN74LV540ANS	TLC37021D
BQ2004HSNTR	SN65MLVD204ADR	SN74F541DB	SN74LV540ANSR	TLC37021DR
BQ2004HSNTRG4	SN65MLVD205AD	SN74F541NS	SN74LV541ADB	TLC3704CNS
BQ2004SN	SN65MLVD205ADR	SN74F541NSR	SN74LV541ADBR	TLC3704CNSR
BQ2004SNG4	SN65MLVD206DR	SN74F543DB	SN74LV541ANS	TLC3704CNSRG4
BQ2004SNTR	SN65MLVD207D	SN74F543NS	SN74LV541ANS-P	TLC372CD
BQ2004SNTRG4	SN7406NS	SN74F74DB	SN74LV541ANSR	TLC372CDR
BQ2040SN-C408TR	SN7406NSR	SN74F74NS	SN74LV541ATNSR	TLC372CPS
BQ2040SN-C408TRG4	SN7407NS	SN74F74NSR	SN74LV573ADB	TLC372CPSG4
BQ2040SN-D111	SN7407NSR	SN74F86NS	SN74LV573ADBR	TLC372CPSR
BQ2954SNTR	SN7407NSRG4	SN74F86NSR	SN74LV573ANS	TLC3721DR
BQ32000D	SN74128NS	SN74GTLPH16612DL	SN74LV573ANSR	TLC374CNS
BQ32000DR	SN74128NSR	SN74HC00ANS	SN74LV574ADBR	TLC374CNSR
BQ3285ESS	SN7414NS	SN74HC00ANSR	SN74LV574ANS	TLC3741D
BQ3285LFSS-A1	SN7414NSR	SN74HC00DB	SN74LV574ANSR	TLC3741DR

日本テキサス・インスツルメンツ株式会社

BQ3285LFSS-A1TR	SN7416NS	SN74HC00DBR	SN74LV595ADR	TLC393CD
BQ77PL900DL	SN7416NSR	SN74HC00NS	SN74LV595ADRG4	TLC393CDR
BQ77PL900DLG4	SN7438NS	SN74HC00NSR	SN74LV595ANS	TLC393CPS
BQ77PL900DLR	SN7438NSR	SN74HC02ANS	SN74LV595ANSR	TLC393CPSR
CD14538BNSR	SN7445NS	SN74HC02ANSR	SN74LV74ANS	TLC3931D
CD4001BNS	SN74ABT125D	SN74HC02DR	SN74LV74ANSR	TLC3931DR
CD4001BNSR	SN74ABT125DB	SN74HC02DRG4	SN74LV86ANS	TLC3931DRG4
CD4002BNS	SN74ABT125DBR	SN74HC02NS	SN74LV86ANSR	TLC4501A1D
CD4002BNSR	SN74ABT125NS	SN74HC02NSR	SN74LVC00ADB	TLC4502ACD
CD40102BNSR	SN74ABT125NSR	SN74HC03DB	SN74LVC00ANS	TLC4502ACDR
CD40106BNSR	SN74ABT126D	SN74HC03NS	SN74LVC00ANSR	TLC4502A1D
CD40107BPSR	SN74ABT126DB	SN74HC03NSR	SN74LVC02AD	TLC4502CD
CD4011BNS	SN74ABT126DBR	SN74HC04ADB	SN74LVC02ADB	TLC4502CDR
CD4011BNSR	SN74ABT126DR	SN74HC04ADBR	SN74LVC02ADBR	TLC45451D
CD4012BNS	SN74ABT126NS	SN74HC04ANS	SN74LVC02ANS	TLC5481D
CD4012BNSR	SN74ABT126NSR	SN74HC04ANSR	SN74LVC02ANSR	TLC549CD
CD4013BNS	SN74ABT162244DLR	SN74HC04DBR	SN74LVC04AD	TLC549CDG4
CD4013BNSR	SN74ABT162245DL	SN74HC04NS	SN74LVC04ADBR	TLC549CDR
CD4015BNS	SN74ABT16240ADL	SN74HC04NS-P	SN74LVC04ADR	TLC5491D
CD40161BNS	SN74ABT16240ADLR	SN74HC04NSR	SN74LVC04ANS	TLC5491PS
CD40161BNSR	SN74ABT16244ADL	SN74HC05ANS	SN74LVC04ANSR	TLC5491PSR
CD4016BNS	SN74ABT16244ADLR	SN74HC05ANSR	SN74LVC06ADR	TLC5510AINS
CD4016BNSR	SN74ABT16245ADL	SN74HC05NS	SN74LVC06ANS	TLC5510AINSR
CD40174BNS	SN74ABT16245ADLR	SN74HC05NSR	SN74LVC06ANSR	TLC5510INSR
CD40175BNS	SN74ABT16373ADL	SN74HC08ADBR	SN74LVC07ADBR	TLC5510INSR-A
CD40175BNSR	SN74ABT16373ADLR	SN74HC08ANS	SN74LVC07ANS	TLC551CD
CD4017BNSR	SN74ABT16374ADL	SN74HC08ANSR	SN74LVC07ANSR	TLC552CDR
CD40193BNSR	SN74ABT16374ADLR	SN74HC08DBR	SN74LVC08AD	TLC5540CNS
CD4019BNSR	SN74ABT16501DL	SN74HC08DRG4	SN74LVC08ADB	TLC55401NS
CD4020BNS	SN74ABT16540ADL	SN74HC08NS	SN74LVC08ADBR	TLC55401NSR
CD4020BNSR	SN74ABT16540ADLR	SN74HC08NS-P	SN74LVC08ADG4	TLC555CD
CD4023BNS	SN74ABT16541ADL	SN74HC08NSR	SN74LVC08ANS	TLC555CDR
CD4024BNSR	SN74ABT16541ADLR	SN74HC109NS	SN74LVC08ANSR	TLC555CDRG4
CD4025BNSR	SN74ABT16543DL	SN74HC109NSR	SN74LVC10ANS	TLC555CPS
CD4026BNSR	SN74ABT16543DLR	SN74HC10ANS	SN74LVC10ANSR	TLC555CPSG4
CD4027BNS	SN74ABT16640DL	SN74HC10ANSR	SN74LVC112ANSR	TLC555CPSR
CD4027BNSR	SN74ABT16640DLR	SN74HC10DBR	SN74LVC125ADB	TLC5551D
CD4028BNS	SN74ABT16652DL	SN74HC10NS	SN74LVC125ADBR	TLC5551DG4
CD4028BNSR	SN74ABT16652DLR	SN74HC10NSR	SN74LVC125ADR	TLC5551DR
CD4030BNSR	SN74ABT16657DL	SN74HC11ADB	SN74LVC125ANS	TLC5551DRG4
CD4040BNSR	SN74ABT16823DLR	SN74HC11ANS	SN74LVC125ANSR	TLC556CD
CD4042BNS	SN74ABT16825DL	SN74HC11ANSR	SN74LVC126ANS	TLC556CDR
CD4042BNSR	SN74ABT2240ANSR	SN74HC11NS	SN74LVC126ANSR	TLC5561D
CD4043BNSR	SN74ABT2244ADBR	SN74HC11NSR	SN74LVC138AD	TLC5561DR
CD4044BNSR	SN74ABT2244ANS	SN74HC125ANS	SN74LVC138ADBR	TLC5615CD
CD4046BNS	SN74ABT2244ANSR	SN74HC125ANSR	SN74LVC138ANS	TLC5620CD
CD4046BNSR	SN74ABT2245NSR	SN74HC125DBR	SN74LVC138ANSR	TLC5620CDR
CD4047BNS	SN74ABT240ADB	SN74HC125NS	SN74LVC139AD	TLC56201D
CD4047BNSR	SN74ABT240ADBR	SN74HC125NSR	SN74LVC139ADBR	TLC56201DR
CD4049UBNS	SN74ABT240ANS	SN74HC126ANS	SN74LVC139ADR	TLC590251DBQR
CD4049UBNSR	SN74ABT240ANSR	SN74HC126ANSR	SN74LVC139ANS	TLC59161D
CD4050BNS	SN74ABT241ANS	SN74HC126DBR	SN74LVC139ANSR	TLC59161DR
CD4050BNSR	SN74ABT244ADB	SN74HC126NS	SN74LVC14ADB	TLC59171D
CD4051BNS	SN74ABT244ADBR	SN74HC126NSR	SN74LVC14ADBR	TLC59171DR
CD4051BNSR	SN74ABT244ANS	SN74HC132ADBR	SN74LVC14ANS	TLC5920DL
CD4052BNS	SN74ABT244ANSR	SN74HC132ANS	SN74LVC14ANS-P	TLC5920DLR
CD4052BNSR	SN74ABT245BDB	SN74HC132ANSR	SN74LVC14ANSR	TLC5920DLRG4

日本テキサス・インスツルメンツ株式会社

CD4053BNS	SN74ABT245BDBR	SN74HC132DBR	SN74LVC157ANS	TLC59251DBQR
CD4053BNSR	SN74ABT245BNS	SN74HC132NS	SN74LVC157ANSR	TLC59281DBQ
CD4056BNS	SN74ABT245BNSR	SN74HC132NS-P	SN74LVC161284DLR	TLC59281DBQR
CD4063BNSR	SN74ABT273DB	SN74HC132NSR	SN74LVC16244ADL	TLC59282DBQ
CD4066BNS	SN74ABT273DBR	SN74HC138ADB	SN74LVC16244ADLR	TLC59282DBQR
CD4066BNSR	SN74ABT273NS	SN74HC138ANS	SN74LVC16245ADL	TLC5928DBQ
CD4068BNSR	SN74ABT273NSR	SN74HC138ANSR	SN74LVC16245ADLR	TLC5928DBQR
CD4069UBNS	SN74ABT373DB	SN74HC138DB	SN74LVC16373ADL	TLC7524CD
CD4069UBNSR	SN74ABT373NS	SN74HC138DBR	SN74LVC16373ADLR	TLC7524CDG4
CD4070BNSR	SN74ABT373NSR	SN74HC138DR	SN74LVC16374ADL	TLC7524CDR
CD4071BNS	SN74ABT374ADBR	SN74HC138NS	SN74LVC16374ADLR	TLC7524CNS
CD4071BNSR	SN74ABT374ANS	SN74HC138NS-P	SN74LVC16T245DL	TLC7524CNSR
CD4072BNSR	SN74ABT374ANSR	SN74HC138NSR	SN74LVC2244ANS	TLC75241D
CD4073BNSR	SN74ABT377ADBR	SN74HC139ADB	SN74LVC2244ANSR	TLC75241DR
CD4075BNSR	SN74ABT377ANS	SN74HC139ADBR	SN74LVC240ADBR	TLC7528CNS
CD4077BNS	SN74ABT377ANSR	SN74HC139ANS	SN74LVC240ANS	TLC7528CNSR
CD4078BNS	SN74ABT534ADB	SN74HC139ANSR	SN74LVC240ANSR	TLC77011D
CD4078BNSR	SN74ABT534ADBR	SN74HC139DBR	SN74LVC244ADB	TLC77011DG4
CD4081BNS	SN74ABT534ANS	SN74HC139NS	SN74LVC244ADBR	TLC77011DR
CD4081BNSR	SN74ABT540DB	SN74HC139NSR	SN74LVC244ANS	TLC77011QD
CD4082BNSR	SN74ABT540DBR	SN74HC148ANS	SN74LVC244ANSR	TLC77031D
CD4093BNS	SN74ABT540NS	SN74HC148ANSR	SN74LVC245ADB	TLC77031DR
CD4093BNSR	SN74ABT540NSR	SN74HC148DB	SN74LVC245ADBR	TLC77051D
CD4094BNS	SN74ABT541BDB	SN74HC148DBR	SN74LVC245ANS	TLC77051DG4
CD4094BNSR	SN74ABT541BDBR	SN74HC148NS	SN74LVC245ANSR	TLC77051DR
CD4099BNSR	SN74ABT541BNS	SN74HC148NSR	SN74LVC257ANS	TLC7705QD
CD4504BNS	SN74ABT541BNSR	SN74HC14ADB	SN74LVC257ANSR	TLC77251D
CD4508BNSR	SN74ABT543ADB	SN74HC14ADBR	SN74LVC32ADB	TLC77251DR
CD4510BNS	SN74ABT543ANS	SN74HC14ANS	SN74LVC32ADBR	TLC7725QD
CD4511BNS	SN74ABT573ADB	SN74HC14ANS-P	SN74LVC32ANS	TLC77331D
CD4511BNSR	SN74ABT573ADBR	SN74HC14ANSR	SN74LVC32ANS-P	TLC77331DG4
CD4512BNSR	SN74ABT573ANS	SN74HC14DB	SN74LVC32ANSR	TLC77331DR
CD4516BNSR	SN74ABT573ANSR	SN74HC14DBR	SN74LVC373ANS	TLC77331DRG4
CD4518BNS	SN74ABT574ADB	SN74HC14NS	SN74LVC373ANSR	TLC7733QD
CD4518BNSR	SN74ABT574ANS	SN74HC14NS-P	SN74LVC374ADB	TLE2064A1D
CD4520BNSR	SN74ABT574ANSR	SN74HC14NSR	SN74LVC374ADBR	TLE2064CD
CD4521BNSR	SN74ABT620NSR	SN74HC151ANS	SN74LVC374ANS	TLE2064CDRG4
CD4527BNS	SN74ABT623NS	SN74HC151ANS-P	SN74LVC374ANSR	TLE2072CPS
CD4532BNS	SN74ABT640DB	SN74HC151ANSR	SN74LVC4245ADB	TLE2425CD
CD4536BNS	SN74ABT640DBR	SN74HC151NS	SN74LVC4245ADBR	TLE2425CPSR
CD4536BNSR	SN74ABT640NS	SN74HC151NSR	SN74LVC540ADB	TLE24251DR
CD4541BNSR	SN74ABT640NSR	SN74HC153ANS	SN74LVC540ADBR	TLE2426CD
CD4543BNS	SN74ABT646ADB	SN74HC153ANSR	SN74LVC540ANS	TLE2426CDR
CD4543BNSR	SN74ABT646ANS	SN74HC153NS	SN74LVC540ANSR	TLE2426CPS
CD4555BNSR	SN74ABT646ANSR	SN74HC153NSR	SN74LVC541ADB	TL9110NSR
CD4572UBNS	SN74ABT821ANS	SN74HC157ANS	SN74LVC541ADBR	TLV0831CD
CD4572UBNSR	SN74ABT841ANS	SN74HC157ANSR	SN74LVC541ANS	TLV08311D
CD74AC00M	SN74ABTE16245DL	SN74HC157DBR	SN74LVC541ANSR	TLV08311DR
CD74AC00M96	SN74ABTE16246DL	SN74HC157NS	SN74LVC573ADBR	TLV0832CDR
CD74AC02M	SN74ABTE16246DLG4	SN74HC157NSR	SN74LVC573ANS	TLV08321D
CD74AC05M	SN74AC00NS	SN74HC158ANS	SN74LVC573ANSR	TLV1543CDBG4
CD74AC05M96G4	SN74AC00NSR	SN74HC158ANSR	SN74LVC574ADBR	TLV15481DB
CD74AC08M	SN74AC04D	SN74HC158NS	SN74LVC574ANS	TLV15481DBR
CD74AC138M	SN74AC04DBR	SN74HC158NSR	SN74LVC574ANSR	TLV1572CD
CD74AC138M96	SN74AC04DR	SN74HC161ANS	SN74LVC74ADB	TLV15721D
CD74AC139M96	SN74AC04NS	SN74HC161ANSE4	SN74LVC74ADR	TLV22541D
CD74AC14M	SN74AC04NSR	SN74HC161ANSR	SN74LVC74ANS	TLV22541DR

日本テキサス・インスツルメンツ株式会社

CD74AC14M96	SN74AC08DBR	SN74HC161NS	SN74LVC74ANSR	TLV2254IDRG4
CD74AC157M96	SN74AC08NS	SN74HC161NSR	SN74LVC827ADB	TLV2332ID
CD74AC158M	SN74AC08NSR	SN74HC163ANS	SN74LVC86ANS	TLV2341ID
CD74AC161M96	SN74AC10NSR	SN74HC163ANSR	SN74LVC86ANSR	TLV2341IDR
CD74AC161M-P	SN74AC11NSR	SN74HC163NS	SN74LVCC3245ADB	TLV2342ID
CD74AC163M	SN74AC14D	SN74HC163NSR	SN74LVCC3245ADBR	TLV2352IDR
CD74AC175M	SN74AC14DBR	SN74HC164ANS	SN74LVCC3245ANS	TLV2422ID
CD74AC238M96E4	SN74AC14DR	SN74HC164ANSR	SN74LVCC3245ANSR	TLV2432AID
CD74AC251M	SN74AC14NS	SN74HC164NS	SN74LVCC4245ADB	TLV2432AIDR
CD74AC541SM96	SN74AC14NSR	SN74HC164NSR	SN74LVCC4245ADBR	TLV2432CD
CD74AC74M	SN74AC14NSRG4	SN74HC165ANS	SN74LVCC4245ANS	TLV2432ID
CD74AC74M96	SN74AC240NS	SN74HC165ANSR	SN74LVCC4245ANSR	TLV2442AID
CD74AC86M	SN74AC240NSR	SN74HC165DR	SN74LVCH162244ADL	TLV2442AIDR
CD74ACT04M96	SN74AC241NS	SN74HC165DRG4	SN74LVCH16240ADL	TLV2442CD
CD74ACT05M	SN74AC241NSR	SN74HC165NS	SN74LVCH16244ADL	TLV2442CDR
CD74ACT05M96	SN74AC244DB	SN74HC165NSR	SN74LVCH16244ADLR	TLV2442ID
CD74ACT08M	SN74AC244NS	SN74HC166ANS	SN74LVCH16245ADL	TLV2442IDR
CD74ACT112M	SN74AC244NSR	SN74HC166ANSR	SN74LVCH16245ADLR	TLV2444AID
CD74ACT112M96	SN74AC245DBR	SN74HC166DBR	SN74LVCH16373ADL	TLV2444CD
CD74ACT138M96	SN74AC245NS	SN74HC166NS	SN74LVCH16373ADLR	TLV2444CDR
CD74ACT139M96	SN74AC245NSR	SN74HC166NSR	SN74LVCH16374ADL	TLV2444IDR
CD74ACT14M	SN74AC32DBR	SN74HC174ANS	SN74LVCH16374ADLR	TLV2454AIDR
CD74ACT14M96	SN74AC32NS	SN74HC174ANSR	SN74LVCH16540ADL	TLV2454CD
CD74ACT153M	SN74AC32NSR	SN74HC174NS	SN74LVCH16541ADL	TLV2465CDR
CD74ACT153NSR	SN74AC373NS	SN74HC174NSR	SN74LVCH16543ADLR	TLV2475AIDR
CD74ACT157M	SN74AC373NSR	SN74HC175ANSR	SN74LVCH244ANS	TLV2541ID
CD74ACT161M	SN74AC374NS	SN74HC175DBR	SN74LVCH244ANSR	TLV2544CD
CD74ACT161M96	SN74AC374NSR	SN74HC175NS	SN74LVCH245ADB	TLV2544CDR
CD74ACT164M	SN74AC534NS	SN74HC175NSR	SN74LVCH245ANS	TLV2622ID
CD74ACT175M	SN74AC534NSR	SN74HC191NS	SN74LVCH245ANSR	TLV2624ID
CD74ACT32M	SN74AC564DB	SN74HC191NSR	SN74LVCHR162245ADL	TLV2764CDR
CD74ACT32M96	SN74AC564DBR	SN74HC193ANSR	SN74LVCHR16245ALR	TLV2772AID
CD74ACT74M	SN74AC573NS	SN74HC193NS	SN74LVGZ240ANS	TLV2772AIDR
CD74ACT74M96	SN74AC573NSR	SN74HC193NSR	SN74LVGZ244ANSR	TLV2772CD
CD74HC112NS	SN74AC74NS	SN74HC20ANS	SN74LVGZ245ANS	TLV2772IDR
CD74HC112NSR	SN74AC74NSR	SN74HC20ANSR	SN74LVGZ245ANSR	TLV2774CD
CD74HC123NS	SN74AC86NS	SN74HC20NS	SN74LVT16240DLR	TLV2774CDR
CD74HC123NSR	SN74AC86NSR	SN74HC20NSR	SN74LVT16244BDL	TLV342AIDR
CD74HC190NSR	SN74ACT00DB	SN74HC21ANS	SN74LVT16244BDLR	TLV3492AID
CD74HC192NSR	SN74ACT00DBR	SN74HC21ANSR	SN74LVT16245BDL	TLV3492AIDR
CD74HC195NSR	SN74ACT00NS	SN74HC21NS	SN74LVT16245BDLG4	TLV3501AID
CD74HC237NSR	SN74ACT00NSR	SN74HC21NSR	SN74LVT16245BDLR	TLV3501AIDR
CD74HC238NS	SN74ACT04D	SN74HC240ADB	SN74LVT240ADB	TLV3502AID
CD74HC238NSR	SN74ACT04DBR	SN74HC240ANS	SN74LVT240ADBR	TLV3502AIDR
CD74HC30NSR	SN74ACT04DR	SN74HC240ANSR	SN74LVT240ADBRG4	TLV5604CD
CD74HC4017NS	SN74ACT04NS	SN74HC240NS	SN74LVT240ANSR	TLV5604CDR
CD74HC4017NSR	SN74ACT04NSR	SN74HC240NSR	SN74LVT244BDB	TLV5604ID
CD74HC4049NS	SN74ACT08NS	SN74HC241ANSR	SN74LVT244BDBR	TLV5606CD
CD74HC4049NSR	SN74ACT08NSR	SN74HC241NS	SN74LVT244BNS	TLV5606ID
CD74HC4050NS	SN74ACT1073NS	SN74HC241NSR	SN74LVT244BNSR	TLV5606IDR
CD74HC4050NSR	SN74ACT1073NSR	SN74HC244ADB	SN74LVT245BDB	TLV5614ID
CD74HC4051NS	SN74ACT10NS	SN74HC244ADBR	SN74LVT245BDBR	TLV5616CD
CD74HC4051NSR	SN74ACT11NS	SN74HC244ANS	SN74LVT245BNS	TLV5616CDR
CD74HC4052NS	SN74ACT1284NS	SN74HC244ANSR	SN74LVT245BNSR	TLV5616ID
CD74HC4052NSR	SN74ACT1284NSR	SN74HC244ANSRG4	SN74LVTH125D	TLV5616IDR
CD74HC4053NSR	SN74ACT14DB	SN74HC244DBR	SN74LVTH125DB	TLV5617ACD
CD74HC4067SM96	SN74ACT14DBR	SN74HC244NS	SN74LVTH125DBR	TLV5617ACDR

日本テキサス・インスツルメンツ株式会社

CD74HC4094NS	SN74ACT14DR	SN74HC244NS-P	SN74LVTH125NS	TLV5617ACDRG4
CD74HC4094NSR	SN74ACT14NS	SN74HC244NSR	SN74LVTH125NSR	TLV5617AID
CD74HC423NSR	SN74ACT14NSR	SN74HC245ANS	SN74LVTH126NS	TLV5617AIDR
CD74HC4316NSR	SN74ACT240DBR	SN74HC245ANSR	SN74LVTH126NSR	TLV5618ACD
CD74HC4538NSR	SN74ACT240NS	SN74HC245DBR	SN74LVTH162240DLR	TLV5618ACDRG4
CD74HC597NSR	SN74ACT240NSR	SN74HC245NS	SN74LVTH162244DL	TLV5618AID
CD74HC688NS	SN74ACT241NS	SN74HC245NSR	SN74LVTH162244DLR	TLV5618AIDR
CD74HC688NSR	SN74ACT241NSR	SN74HC251ANSR	SN74LVTH162245DL	TLV5620CD
CD74HC85NS	SN74ACT244DB	SN74HC251NS	SN74LVTH162245DLR	TLV5620CDG4
CD74HC85NSR	SN74ACT244DBR	SN74HC251NSR	SN74LVTH162373DLR	TLV5620CDR
CDC208NS	SN74ACT244NS	SN74HC253ANSR	SN74LVTH162374DL	TLV5620ID
CDC208NSR	SN74ACT244NSR	SN74HC253DBR	SN74LVTH162374DLR	TLV5623CD
CDC2351DB	SN74ACT245DBR	SN74HC253NS	SN74LVTH16240DL	TLV5623CDR
CDC2351DBG4	SN74ACT245NS	SN74HC253NSR	SN74LVTH16240DLR	TLV5623ID
CDC2351DBR	SN74ACT245NSR	SN74HC257ANSR	SN74LVTH16241DL	TLV5623IDR
CDC2536DB	SN74ACT32D	SN74HC257NS	SN74LVTH16244ADL	TLV5624ID
CDC2536DBR	SN74ACT32NS	SN74HC257NSR	SN74LVTH16244ADLR	TLV5624IDG4
CDC303NS	SN74ACT32NSR	SN74HC258NSR	SN74LVTH16245ADL	TLV5624IDR
CDC303NSR	SN74ACT373NS	SN74HC259ANS	SN74LVTH16245ADLR	TLV5625CD
CDC318ADLG4	SN74ACT373NSR	SN74HC259ANSR	SN74LVTH16373DL	TLV5625CDR
CDC319DB	SN74ACT374DBR	SN74HC259NS	SN74LVTH16373DLR	TLV5625ID
CDC328AD	SN74ACT374NSR	SN74HC259NSR	SN74LVTH16374DLR	TLV5625IDG4
CDC328ADB	SN74ACT533NS	SN74HC266ANS	SN74LVTH16501DL	TLV5625IDR
CDC328ANS	SN74ACT534NS	SN74HC266ANSR	SN74LVTH16952DL	TLV5625IDRG4
CDC329AD	SN74ACT534NSR	SN74HC266NSR	SN74LVTH2245NS	TLV5626CD
CDC341NS	SN74ACT564NS	SN74HC273ADB	SN74LVTH240DB	TLV5626CDR
CDC351DB	SN74ACT573NS	SN74HC273ANS	SN74LVTH240DBR	TLV5626ID
CDC351DBG4	SN74ACT573NSR	SN74HC273ANSR	SN74LVTH240NS	TLV5626IDRG4
CDC351DBR	SN74ACT574DB	SN74HC273DBR	SN74LVTH240NSR	TLV5627CD
CDC351NS	SN74ACT574DBR	SN74HC273NS	SN74LVTH244ADB	TLV5636CD
CDC351NSR	SN74ACT574NS	SN74HC273NS-P	SN74LVTH244ADB	TLV5636ID
CDC536DB	SN74ACT574NSR	SN74HC273NSR	SN74LVTH244ANS	TLV5636IDR
CDC536DBG4	SN74ACT74NS	SN74HC27ADB	SN74LVTH244ANSR	TLV5637CD
CDC536DBR	SN74ACT74NSR	SN74HC27ANS	SN74LVTH245ADB	TLV5637ID
CDC5801ADBQ	SN74ACT7804-40DL	SN74HC27ANSR	SN74LVTH245ADB	TLV5637IDG4
CDCF5801ADBQ	SN74ACT86NSR	SN74HC27NS	SN74LVTH245ANS	TLV5637IDR
CDCF5801DBQ	SN74ACT86NSRG4	SN74HC27NSR	SN74LVTH245ANSR	TLV5638CD
CDCFR83ADBQ	SN74AHC00DBR	SN74HC32ANS	SN74LVTH245ANSRG4	TLV5638CDG4
CDCFR83ADBQR	SN74AHC00DR	SN74HC32ANSR	SN74LVTH273NSR	TLV5638CDR
CDCR83ADBQR	SN74AHC00NS	SN74HC32DBR	SN74LVTH373DB	TLV5638CDRG4
CDCVF2505D	SN74AHC00NSR	SN74HC32DR	SN74LVTH373DBR	TLV5638ID
CDCVF2505DG4	SN74AHC02NS	SN74HC32NS	SN74LVTH373NS	TLV5638IDR
CDCVF2505DR	SN74AHC02NSR	SN74HC32NS-P	SN74LVTH373NSR	TMP124AID
CDCVF2505DRG4	SN74AHC04D	SN74HC32NSR	SN74LVTH374DB	TMP175AID
CDCVF2508ID	SN74AHC04DBR	SN74HC365ANSR	SN74LVTH374NS	TMP175AIDR
CF45538NSRG4	SN74AHC04DR	SN74HC365NS	SN74LVTH374NSR	TMP275AID
CY74FCT16244ATPVC	SN74AHC04NS	SN74HC365NSR	SN74LVTH540NS	TMP400AIDBQR
CY74FCT16827CTPVCT	SN74AHC04NSR	SN74HC367ANS	SN74LVTH541DB	TMP75AID
CY74FCT245ATQCT	SN74AHC05DBR	SN74HC367ANSR	SN74LVTH541DBR	TMP75AIDG4
CY74FCT540CTQCT	SN74AHC05NS	SN74HC367NS	SN74LVTH541NS	TMP75AIDR
CY74FCT541TQCT	SN74AHC05NSR	SN74HC367NS-P	SN74LVTH541NSR	TMP75AIDRG4
CY74FCT573ATQCT	SN74AHC08DBR	SN74HC367NSR	SN74LVTH543DBR	TMS3705A1DRG4
DAC1220E	SN74AHC08NS	SN74HC368ANS	SN74LVTH543NS	TMS3705BDRG4
DAC1220E/2K5	SN74AHC08NSR	SN74HC368ANSR	SN74LVTH573DB	TPA6111A2DR
DAC1220EG4	SN74AHC125DG4	SN74HC368NSR	SN74LVTH573DBR	TPPM0115D
DSD1702E/2K	SN74AHC125DR	SN74HC373ANS	SN74LVTH573NS	TPPM0115DR
GD75232DBR	SN74AHC125NS	SN74HC373ANSR	SN74LVTH573NSR	TPPM0301DR

日本テキサス・インスツルメンツ株式会社

HPA00231DR	SN74AHC125NSR	SN74HC373DBR	SN74LVTH574DB	TPS1101D
HPA01061DTR-4	SN74AHC126NS	SN74HC373NS	SN74LVTH574DBR	TPS2010AD
INA155UA	SN74AHC126NSR	SN74HC373NSR	SN74LVTH574NS	TPS2011AD
INA155UAG4	SN74AHC138NS	SN74HC374ADB	SN74LVTH574NSR	TPS2011D
INA200AID	SN74AHC138NSR	SN74HC374ANS	SN74LVU04ANS	TPS2011DR
INA219AID	SN74AHC139NS	SN74HC374ANSR	SN74LVU04ANSR	TPS2012AD
INA219BIDR	SN74AHC139NSR	SN74HC374DBR	SN74S04NS	TPS2012ADR
INA270AID	SN74AHC14DBR	SN74HC374NS	SN74S04NSR	TPS2012ADRG4
INA271AIDR	SN74AHC14NS	SN74HC374NSR	SN74S05NS	TPS2013AD
INA282AID	SN74AHC14NSR	SN74HC377ANS	SN74S05NSR	TPS2013ADR
INA282AIDR	SN74AHC157NS	SN74HC377ANSR	SN74S08NS	TPS2013D
LM2901NS	SN74AHC157NSR	SN74HC377NS	SN74S09NSR	TPS2014D
LM2901NSR	SN74AHC16244DL	SN74HC393ANS	SN74S1050NS	TPS2014DG4
LM2902NS	SN74AHC16244DLR	SN74HC393ANSR	SN74S1051DBR	TPS2014DR
LM2902NSR	SN74AHC16373DL	SN74HC393NS	SN74S1051NS	TPS2014DRG4
LM2903PS	SN74AHC16373DLR	SN74HC393NS-P	SN74S1051NSR	TPS2015DR
LM2903PSR	SN74AHC16374DL	SN74HC393NSR	SN74S1052DBR	TPS2020D
LM2904PS-JF	SN74AHC16374DLR	SN74HC4020ANS	SN74S1052NS	TPS2020DR
LM2904PSR-JF	SN74AHC16541DLR	SN74HC4020ANSR	SN74S1052NSR	TPS2021D
LM311PS	SN74AHC240NS	SN74HC4020NS	SN74S1053DB	TPS2021DG4
LM311PSR	SN74AHC240NSR	SN74HC4020NS-P	SN74S1053DBR	TPS2021DR
LM318PS	SN74AHC244DBR	SN74HC4020NSR	SN74S1053NS	TPS2022D
LM318PSR	SN74AHC244NS	SN74HC4040ANS	SN74S1053NSR	TPS2022DR
LM324ANS	SN74AHC244NSR	SN74HC4040ANSR	SN74S140NS	TPS2023D
LM324ANSR	SN74AHC245NS	SN74HC4040NS	SN74S140NSR	TPS2023DR
LM324NS	SN74AHC245NSR	SN74HC4040NSR	SN74S151NS	TPS2024D
LM324NSR	SN74AHC273DBR	SN74HC4060ADB	SN74S20NSR	TPS2024DR
LM339ANS	SN74AHC273NS	SN74HC4060ANS	SN74S37NS	TPS2024DRG4
LM339ANSR	SN74AHC273NSR	SN74HC4060NS	SN74S38NS	TPS2030D
LM339ANSRG4	SN74AHC32DBR	SN74HC4060NSR	SN74S38NSR	TPS2030DR
LM339DBR	SN74AHC32NS	SN74HC4066DBR	SN74S74NS	TPS2031D
LM339NS	SN74AHC32NSR	SN74HC4066NS	SN74S74NSR	TPS2031DG4
LM339NSR	SN74AHC373NSR	SN74HC4066NSR	SN75107ANS	TPS2031DR
LM339NSRG4	SN74AHC374NS	SN74HC42NS	SN75107ANSR	TPS2032D
LM348NS	SN74AHC374NSR	SN74HC42NSR	SN75107BNS	TPS2032DR
LM348NSR	SN74AHC4066DBR	SN74HC540ANS	SN75107BNSR	TPS2033D
LM358PS	SN74AHC4066NSR	SN74HC540ANSR	SN75110ANS	TPS2033DR
LM358PS-JF	SN74AHC540NS	SN74HC540NS	SN75113NS	TPS2034D
LM358PSR	SN74AHC541NS	SN74HC540NSR	SN75113NSR	TPS2034DR
LM358PSR-JF	SN74AHC541NSR	SN74HC541ANS	SN75115NS	TPS2034DRG4
LM385PS-1-2	SN74AHC573NS	SN74HC541ANS-P	SN75115NSR	TPS2041AD
LM393APS	SN74AHC573NSR	SN74HC541ANSR	SN75116NS	TPS2041ADR
LM393APSR	SN74AHC574NS	SN74HC541DB	SN75116NSR	TPS2041BD
LM393PS	SN74AHC574NSR	SN74HC541DBR	SN751177NS	TPS2041BDR
LM393PS-P	SN74AHC594NSR	SN74HC541NS	SN751177NSG4	TPS2041D
LM393PSR	SN74AHC595DBR	SN74HC541NS-P	SN751177NSR	TPS2041DR
LMV324ID	SN74AHC74DR	SN74HC541NSR	SN751178NS	TPS2042AD
LMV324IDR	SN74AHC74NS	SN74HC563NS	SN751178NSR	TPS2042ADG4
LMV324IDRG4	SN74AHC74NSR	SN74HC563NSR	SN75118NS	TPS2042ADR
LMV342ID	SN74AHC86NS	SN74HC573BNS	SN75121NS	TPS2042BD
LMV342IDR	SN74AHC86NSR	SN74HC573BNSR	SN75121NSR	TPS2042BDG4
LMV344IDR	SN74AHCT00NS	SN74HC573NS	SN75124NS	TPS2042BDR
LMV358ID	SN74AHCT00NSR	SN74HC573NSR	SN75124NSR	TPS2042BDRG4
LMV358IDR	SN74AHCT02NS	SN74HC574ANS	SN75138NS	TPS2042D
LMV358IDRG4	SN74AHCT04DB	SN74HC574ANSR	SN75138NSR	TPS2042DG4
LMV393ID	SN74AHCT04NS	SN74HC574DBR	SN75140PS	TPS2043BD
LMV393IDR	SN74AHCT04NSR	SN74HC574NS	SN75140PSR	TPS2043BDR

日本テキサス・インスツルメンツ株式会社

LMV3931DRG4	SN74AHCT08NS	SN74HC574NS-P	SN75154NS	TPS2043BDRG4
LP311PS	SN74AHCT08NSR	SN74HC574NSR	SN75157PS	TPS2043D
LP311PSE4	SN74AHCT125NS	SN74HC595ADB	SN75157PSR	TPS2044ADR
MAX207CDB	SN74AHCT125NSR	SN74HC595ADBR	SN75158PS	TPS2044BD
MAX207CDBR	SN74AHCT126DR	SN74HC595ANS	SN75158PSR	TPS2044BDG4
MAX208CDBR	SN74AHCT126NS	SN74HC595ANSR	SN751701PS	TPS2044BDR
MAX208IDB	SN74AHCT126NSR	SN74HC595DBR	SN751701PSR	TPS2044BDRG4
MAX208IDBR	SN74AHCT132NS	SN74HC595DR	SN751730NS	TPS2044D
MAX211CDB	SN74AHCT138DBR	SN74HC595DRG4	SN75173NS	TPS2044DR
MAX211CDBR	SN74AHCT138NS	SN74HC595NS	SN75173NSR	TPS2044DRG4
MAX211IDB	SN74AHCT138NSR	SN74HC595NS-P	SN75175NS	TPS2045ADR
MAX213IDB	SN74AHCT14NS	SN74HC595NSR	SN75175NSR	TPS2045ADR4
MAX213IDBR	SN74AHCT14NSR	SN74HC623NS	SN75175NSRE4	TPS2046BDR
MAX232NS	SN74AHCT157DBR	SN74HC623NSR	SN75176BPS	TPS2048AD
MAX232NSR	SN74AHCT16240DLR	SN74HC640ANS	SN75176BPSG4	TPS2048ADR
MAX3221CDB	SN74AHCT16244DLR	SN74HC640ANSR	SN75176BPSR	TPS2048ADR4
MAX3221CDBR	SN74AHCT16245DL	SN74HC640NS	SN75176BPSRG4	TPS2049DR
MAX3221ECDB	SN74AHCT16245DLR	SN74HC640NSR	SN75178BPS	TPS2049DRG4
MAX3221ECDBR	SN74AHCT16540DL	SN74HC645ANS	SN75179BPS	TPS2051AD
MAX3221EIDB	SN74AHCT16541DL	SN74HC645NS	SN75179BPSR	TPS2051ADR
MAX3221EIDBR	SN74AHCT16541DLR	SN74HC74ADB	SN75179BPSRE4	TPS2051BD
MAX3221IDB	SN74AHCT240NSR	SN74HC74ADBR	SN75182NS	TPS2051BDG4
MAX3221IDBR	SN74AHCT244DB	SN74HC74ANS	SN75182NSR	TPS2051BDR
MAX3222CDB	SN74AHCT244DBR	SN74HC74ANSR	SN75183NS	TPS2051BDR4
MAX3222CDBR	SN74AHCT244NS	SN74HC74DB	SN75183NSR	TPS2052AD
MAX3222ECDB	SN74AHCT244NSR	SN74HC74DBR	SN75188NS	TPS2052ADG4
MAX3222EIDB	SN74AHCT245DB	SN74HC74NS	SN75188NSR	TPS2052ADR
MAX3222EIDBR	SN74AHCT245NS	SN74HC74NSR	SN75189ANS	TPS2052BD
MAX3222IDB	SN74AHCT245NSR	SN74HC86ANS	SN75189ANSR	TPS2052BDR
MAX3222IDBR	SN74AHCT273NS	SN74HC86ANSR	SN75189ANSRG4	TPS2052BDRG4
MAX3223CDB	SN74AHCT273NSR	SN74HC86NS	SN75189NS	TPS2052DR
MAX3223ECDBR	SN74AHCT32NS	SN74HC86NSR	SN75189NSR	TPS2053BDR
MAX3223EIDBR	SN74AHCT32NSR	SN74HCT00ANS	SN75207BNSR	TPS2054BD
MAX3223IDB	SN74AHCT373NSR	SN74HCT00ANSR	SN7534050NS	TPS2054BDR
MAX3223IDBR	SN74AHCT540NS	SN74HCT00NSR	SN7534050NSR	TPS2055AD
MAX3227EIDB	SN74AHCT540NSR	SN74HCT02ANS	SN7534051NS	TPS2055ADR
MAX3227IDBR	SN74AHCT540NSRE4	SN74HCT02ANSR	SN7534051NSR	TPS2055ADR4
MAX3232CDB	SN74AHCT541DBR	SN74HCT02NSR	SN75372PS	TPS2056AD
MAX3232CDBR	SN74AHCT541NS	SN74HCT04ADBR	SN75372PSR	TPS2056ADG4
MAX3232ECDB	SN74AHCT541NS-P	SN74HCT04ANS	SN75374D	TPS2056ADR
MAX3232ECDBR	SN74AHCT541NSR	SN74HCT04ANSR	SN75374DR	TPS2056D
MAX3232EIDB	SN74AHCT573DBR	SN74HCT04NS	SN75374DRE4	TPS2061D
MAX3232EIDBR	SN74AHCT574NSR	SN74HCT04NSR	SN75451BPS	TPS2061DR
MAX3232IDB	SN74AHCT594NSR	SN74HCT08ANS	SN75451BPSR	TPS2062AD
MAX3232IDBR	SN74AHCT74D	SN74HCT08ANSR	SN75452BPS	TPS2062ADR
MAX3237EIDB	SN74AHCT74NS	SN74HCT08NSR	SN75452BPSR	TPS2062D
MAX3237EIDBR	SN74AHCT74NSR	SN74HCT138ANS	SN75452BPSRE4	TPS2062DG4
MAX3238CDB	SN74AHCT86NSR	SN74HCT138DB	SN75453BPS	TPS2062DR
MAX3238CDBR	SN74AHCU04DBR	SN74HCT138NS	SN75453BPSR	TPS2065D
MAX3238EIDB	SN74AHCU04NSR	SN74HCT138NSR	SN75454BPS	TPS2065DR
MAX3238IDB	SN74ALS00ANS	SN74HCT138NSRG4	SN75454BPSR	TPS2066AD
MAX3238IDBR	SN74ALS00ANSR	SN74HCT14DR	SN75468NS	TPS2066ADR
MAX3243CDB	SN74ALS02ANS	SN74HCT240ANS	SN75468NSR	TPS2066D
MAX3243CDBR	SN74ALS02ANSR	SN74HCT240ANSR	SN75970B1DL	TPS2066DR
MAX3243ECDB	SN74ALS04BDB	SN74HCT240NS	SN75970B2DL	TPS2067DR
MAX3243ECDBR	SN74ALS04BDBR	SN74HCT240NSR	SN75971B1DL	TPS2068D
MAX3243EIDB	SN74ALS04BNS	SN74HCT244ADB	SN75971B2DL	TPS2068DR

日本テキサス・インスツルメンツ株式会社

MAX3243EIDBR	SN74ALS04BNSR	SN74HCT244ANS	SN75976A1DL	TPS2080D
MAX3243IDB	SN74ALS05ADB	SN74HCT244ANSR	SN75976A1DLR	TPS2081D
MAX3243IDBR	SN74ALS05ANS	SN74HCT244DB	SN75976A2DL	TPS2082D
MAX3318IDB	SN74ALS05ANSR	SN74HCT244DBR	SN75ALS1177NS	TPS2082DR
MC1458PSR	SN74ALS08DB	SN74HCT244NS	SN75ALS1177NSR	TPS2087D
MC3403DBR	SN74ALS08NS	SN74HCT244NSR	SN75ALS1178NS	TPS2090D
MC3403NSR	SN74ALS08NSR	SN74HCT245ANS	SN75ALS1178NSR	TPS2090DR
MC3486NS	SN74ALS08NSRG4	SN74HCT245ANSR	SN75ALS1178NSRG4	TPS2092DR
MC3486NSR	SN74ALS09NS	SN74HCT245DB	SN75ALS173NS	TPS2202AIDB
MC3487NS	SN74ALS1004NS	SN74HCT245DBR	SN75ALS173NSE4	TPS2202AIDBRG4
MC3487NSR	SN74ALS1004NSR	SN74HCT245NS	SN75ALS173NSR	TPS2205IDB
MSP430F4250IDL	SN74ALS1005NSR	SN74HCT245NSR	SN75ALS173NSRG4	TPS2205IDBR
MSP430F4250IDLR	SN74ALS1034NS	SN74HCT273ANS	SN75ALS175NS	TPS2206ADB
MSP430F4260IDL	SN74ALS1034NSR	SN74HCT273ANSR	SN75ALS175NSR	TPS2206ADBR
MSP430F4270IDL	SN74ALS109ANS	SN74HCT273DB	SN75ALS181NS	TPS2206IDB
MSP430F4270IDLR	SN74ALS109ANSR	SN74HCT273DBR	SN75ALS181NSE4	TPS2206IDBR
NE5532APS	SN74ALS10ANS	SN74HCT273NS	SN75ALS181NSR	TPS2211AIDB
NE5532APSR	SN74ALS10ANSR	SN74HCT273NS-P	SN75ALS191PS	TPS2211AIDBR
NE5532PS	SN74ALS112ANS	SN74HCT273NSR	SN75ALS191PSR	TPS2211IDB
NE5532PSR	SN74ALS112ANSR	SN74HCT32ANS	SN75ALS192NS	TPS2211IDBG4
NE5534PS	SN74ALS11ANS	SN74HCT32ANSR	SN75ALS192NSR	TPS2211IDBR
NE555PS	SN74ALS11ANSR	SN74HCT32DBR	SN75ALS192NSRE4	TPS2211IDBRG4
NE555PSR	SN74ALS133NS	SN74HCT32NS	SN75ALS194NS	TPS2212IDB
NE555PSRE4	SN74ALS133NSR	SN74HCT32NSR	SN75ALS194NSR	TPS2214ADB
NE556DB	SN74ALS138ADB	SN74HCT373ANSR	SN75ALS197NS	TPS2214ADBR
NE556DBR	SN74ALS138ANS	SN74HCT373NS	SN75ALS197NSR	TPS2216ADB
NE556NS	SN74ALS138ANSR	SN74HCT373NSR	SN75C1167DB	TPS2216DB
NE556NS-P	SN74ALS139NS	SN74HCT374ANS	SN75C1167DBR	TPS2216DBR
NE556NSR	SN74ALS139NSR	SN74HCT374ANSR	SN75C1167DBRG4	TPS2220ADBR
OP-07DPS	SN74ALS151NS	SN74HCT374NS	SN75C1167NS	TPS2220BDBR
OP-07DPSR	SN74ALS151NSR	SN74HCT374NSR	SN75C1167NSR	TPS2223ADB
OP-07DPSRE4	SN74ALS153NS	SN74HCT541ANS	SN75C1168DB	TPS2223ADBR
OP-07DPSRG4	SN74ALS153NSR	SN74HCT541ANSR	SN75C1168DBR	TPS2223ADBRG4
OPA1632D	SN74ALS157ADB	SN74HCT541DB	SN75C1168NS	TPS2226ADB
OPA1632DR	SN74ALS157ANS	SN74HCT541DBR	SN75C1168NSR	TPS2226ADBG4
OPA1662AID	SN74ALS157ANSR	SN74HCT541NS	SN75C1406NS	TPS2226DBR
OPA2330AID	SN74ALS158NS	SN74HCT541NSR	SN75C1406NSR	TPS2371DG4
OPA2330AIDR	SN74ALS161BNS	SN74HCT573ANSR	SN75C188NS	TPS2371DR
OPA2333AID	SN74ALS161BNSR	SN74HCT573NS	SN75C188NSR	TPS2375D
OPA2333AIDG4	SN74ALS163BNS	SN74HCT573NSR	SN75C189ADB	TPS2375DR
OPA2333AIDR	SN74ALS163BNSR	SN74HCT574ANS	SN75C189ADBR	TPS2376D
OPA2335AID	SN74ALS1645ANSR	SN74HCT574ANSR	SN75C189ANS	TPS2376DG4
OPA2335AIDG4	SN74ALS164ANS	SN74HCT574NS	SN75C189ANSR	TPS2811D
OPA2335AIDR	SN74ALS166NS	SN74HCT574NSR	SN75C189NS	TPS2811DR
OPA2336U/2K5	SN74ALS166NSR	SN74HCT74ANSR	SN75C189NSR	TPS2812D
OPA2336UA	SN74ALS169BNS	SN74HCT74NSR	SN75C3232DB	TPS2812DR
OPA2336UA/2K5	SN74ALS174NS	SN74HCU04ADBR	SN75C3232EDBR	TPS2814D
OPA2336UA/2K5G4	SN74ALS174NSR	SN74HCU04ANS	SN75C3238DBR	TPS2814DR
OPA2337UA	SN74ALS175NS	SN74HCU04ANSR	SN75C3238EDB	TPS2814DRG4
OPA2337UA/2K5	SN74ALS175NSR	SN74HCU04DBR	SN75C3243DB	TPS28225D
OPA2337UA/2K5G4	SN74ALS191ANS	SN74HCU04NS	SN75C3243DBR	TPS40200D
OPA2337UAG4	SN74ALS193ANS	SN74HCU04NSR	SN75HVD05D	TPS40200DR
OPA2338UA/2K5	SN74ALS193ANSR	SN74LS00DB	SN75HVD07DR	TPS40200GDR
OPA2342UA	SN74ALS20ANS	SN74LS00DBR	SN75HVD08D	TPS5103IDBR
OPA2342UA/2K5	SN74ALS20ANSR	SN74LS00NS	SN75HVD08DR	TPS5410D
OPA2343UA	SN74ALS21ANS	SN74LS00NSR	SN75HVD10D	TPS5410DG4
OPA2343UA/2K5	SN74ALS21ANSR	SN74LS00PSR	SN75HVD10DR	TPS5410D-P

日本テキサス・インスツルメンツ株式会社

OPA2343UA/2K5G4	SN74ALS240A-1NS	SN74LS02NS	SN75HVD1176D	TPS5410DR
OPA2344UA	SN74ALS240A-1NSR	SN74LS02NSR	SN75HVD1176DR	TPS5420D
OPA2348AID	SN74ALS240ADB	SN74LS02NSRG4	SN75HVD11D	TPS5420DG4
OPA2348AIDG4	SN74ALS240ADBR	SN74LS03NS	SN75HVD11DG4	TPS5420D-P
OPA2348AIDR	SN74ALS240ANS	SN74LS03NSR	SN75HVD11DR	TPS5420DR
OPA2349UA	SN74ALS240ANSR	SN74LS04DB	SN75HVD12D	TPS5420DRG4
OPA2353UA	SN74ALS241CNSR	SN74LS04DBR	SN75HVD12DR	TPS54231D
OPA2353UA/2K5	SN74ALS243ANSR	SN74LS04NS	SN75LBC173D	TPS54231DR
OPA2356AID	SN74ALS244C-1DB	SN74LS04NSR	SN75LBC173DR	TPS54232D
OPA2356AIDR	SN74ALS244C-1DBR	SN74LS05NS	SN75LBC175D	TPS54232DR
OPA2364AID	SN74ALS244C-1NS	SN74LS05NSR	SN75LBC175DG4	TPS54233D
OPA2364AIDR	SN74ALS244C-1NSR	SN74LS06DB	SN75LBC175DR	TPS54233DR
OPA2364ID	SN74ALS244C-1NSRG4	SN74LS06DBR	SN75LBC176D	TPS54331D
OPA2365AID	SN74ALS244CDB	SN74LS06DBRG4	SN75LBC176DR	TPS54331D-P
OPA2365AIDG4	SN74ALS244CDBR	SN74LS06NS	SN75LBC179D	TPS54331DR
OPA2365AIDR	SN74ALS244CNS	SN74LS06NSE4	SN75LBC179DG4	TPS54331GDR
OPA2374AID	SN74ALS244CNSR	SN74LS06NSR	SN75LBC179DR	TPS6734ID
OPA2379AID	SN74ALS244CNSRG4	SN74LS06NSRG4	SN75LBC179DRG4	TPS67351D
OPA2379AIDR	SN74ALS245A-1DB	SN74LS07DB	SN75LBC180D	TPS67351DR
OPA2674I-14D	SN74ALS245A-1DBR	SN74LS07DBR	SN75LBC180DR	TPS67551D
OPA2674ID	SN74ALS245A-1NS	SN74LS07DBRG4	SN75LBC180DRG4	TPS7101QD
OPA2674IDRG4	SN74ALS245A-1NSR	SN74LS07NS	SN75LBC182D	TPS7101QDR
OPA2735AID	SN74ALS245ADB	SN74LS07NS-P	SN75LBC184D	TPS71025D
OPA2735AIDG4	SN74ALS245ADBR	SN74LS07NSR	SN75LBC184DR	TPS7133QD
OPA2735AIDR	SN74ALS245ANS	SN74LS07NSRG4	SN75LBC968DL	TPS7133QDR
OPA2743UA	SN74ALS245ANSR	SN74LS08DB	SN75LBC968DLR	TPS7148QD
OPA2830ID	SN74ALS251NS	SN74LS08DBR	SN75LV4737ADB	TPS7201QD
OPA2830IDR	SN74ALS253NSR	SN74LS08NS	SN75LV4737ADBR	TPS7201QDR
OPA2846ID	SN74ALS257ADB	SN74LS08NSR	SN75LVCP422DB	TPS7233QD
OPA2889IDR	SN74ALS257ANS	SN74LS09NS	SN75LVDS390D	TPS7301QD
OPA2890ID	SN74ALS257ANSR	SN74LS09NSR	SN75LVDS390DG4	TPS7330QD
OPA2890IDR	SN74ALS273DB	SN74LS107ANS	SN75LVDS391D	TPS7333QD
OPA301AIDR	SN74ALS273DBR	SN74LS107ANSR	SN75LVDT390D	TPS7333QDR
OPA333AID	SN74ALS273NS	SN74LS109ANS	SN761028DLR	TPS7333QDRG4
OPA3355UA	SN74ALS273NSR	SN74LS109ANSR	SN761029DLR	TPS7350QD
OPA335AID	SN74ALS27ANS	SN74LS10NS	SRC4180IDBR	TPS7350QDR
OPA336U	SN74ALS27ANSR	SN74LS10NSR	SRC4182IDB	TPS7418DG4
OPA336U/2K5	SN74ALS27ANSRG4	SN74LS112ANS	SRC4182IDBR	TPS7433D
OPA336U/2K5G4	SN74ALS30ADB	SN74LS112ANSR	SRC4190IDB	TPS7433DR
OPA336UA	SN74ALS30ANS	SN74LS11NS	SRC4190IDB-P	TRS207CDBR
OPA336UA/2K5	SN74ALS30ANSR	SN74LS11NSR	SRC4190IDBR	TRS208IDB
OPA337UA	SN74ALS32DB	SN74LS123DB	SRC4190IDBRG4	TRS208IDBR
OPA344UA	SN74ALS32NS	SN74LS123DBR	SRC4192IDB	TRS3221ECDB
OPA345UA	SN74ALS32NSR	SN74LS123NS	SRC4192IDBR	TRS3221ECDBR
OPA350UA	SN74ALS32NSRG4	SN74LS123NSR	SRC4193IDB	TRS3221EIDB
OPA350UA/2K5	SN74ALS373ADB	SN74LS125ADB	SRC4193IDBR	TRS3221EIDBR
OPA350UAG4	SN74ALS373ADBR	SN74LS125ADBR	TB5D2HD	TRS3222EIDB
OPA353UA	SN74ALS373ANS	SN74LS125ANS	TB5R1D	TRS3232ECDBR
OPA355UA	SN74ALS373ANSR	SN74LS125ANSR	TB5R1DE4	TRS3237EIDB
OPA355UA/2K5	SN74ALS373ANSRG4	SN74LS126ANS	TB5T1D	TRS3237EIDBR
OPA356AID	SN74ALS374ANS	SN74LS126ANSR	THS3001CD	TRS3238ECDB
OPA356AIDR	SN74ALS374ANSR	SN74LS132NS	THS3001CDG4	TRS3243CDBR
OPA363ID	SN74ALS37ANS	SN74LS132NSR	THS3001ID	TRS3243ECDB
OPA363IDG4	SN74ALS38BNS	SN74LS136NS	THS3061D	TRS3243ECDBR
OPA364ID	SN74ALS38BNSR	SN74LS136NSR	THS3062D	TRS3243ECDBRG4
OPA365AID	SN74ALS520DB	SN74LS138NS	THS3091D	TRS3243EIDB
OPA3693IDBQ	SN74ALS520NS	SN74LS138NSR	THS3091DG4	TRS3318ECDB

日本テキサス・インスツルメンツ株式会社

OPA379AID	SN74ALS520NSR	SN74LS139ANS	THS3092D	TRSF3221ECDB
OPA380AID	SN74ALS521NS	SN74LS139ANSR	THS3110IDG4	TRSF3232EIDBR
OPA380AIDR	SN74ALS533ANSR	SN74LS145NS	THS3110IDRG4	TS3A5018DBQR
OPA4330AID	SN74ALS534ADB	SN74LS145NSR	THS3120ID	TS3L100DBQR
OPA4336EA/250	SN74ALS534ANS	SN74LS148NS	THS3121CD	TS3L110DBQR
OPA4336EA/250G4	SN74ALS534ANSR	SN74LS148NSR	THS3122CD	TS3L110DR
OPA4336EA/2K5	SN74ALS540-1NS	SN74LS14DB	THS3122CDR	TS3V330D
OPA4336EA/2K5G4	SN74ALS540-1NSR	SN74LS14DBR	THS3122ID	TS3V340DBQR
OPA4342UA	SN74ALS540NS	SN74LS14NS	THS3201D	TXB0104D
OPA4343UA/2K5	SN74ALS540NSR	SN74LS14NSR	THS3202D	TXB0104DR
OPA4347UA	SN74ALS540NSRG4	SN74LS151NS	THS4001CD	TXS0104ED
OPA4348AID	SN74ALS541-1DB	SN74LS151NSR	THS4001CDR	TXS0104EDR
OPA4348AIDR	SN74ALS541-1NS	SN74LS153NS	THS4001ID	UA723CNS
OPA4353EA/250	SN74ALS541-1NSR	SN74LS153NSR	THS4011CD	UA723CNSR
OPA4353EA/250G4	SN74ALS541DB	SN74LS155ANSR	THS4011ID	UA733CNS
OPA4353UA/2K5	SN74ALS541DBR	SN74LS156NS	THS4011IDG4	UA733CNSR
OPA4354AID	SN74ALS541NS	SN74LS156NSR	THS4012CD	UA741CPSR
OPA4354AIDR	SN74ALS541NSR	SN74LS157DBR	THS4012ID	UA9637ACPS
OPA4364AID	SN74ALS541NSRG4	SN74LS157NS	THS4012IDG4	UCC24610DR
OPA4364AIDG4	SN74ALS563BNSR	SN74LS157NSR	THS4021ID	UCC25600D
OPA4364AIDR	SN74ALS563BNSRG4	SN74LS158NS	THS4021IDR	UCC25600DR
OPA4364AIDRG4	SN74ALS564BNS	SN74LS158NSR	THS4022ID	UCC25600DR-G
OPA615ID	SN74ALS564BNSG4	SN74LS161ANS	THS4031CD	UCC25701DTR
OPA615IDR	SN74ALS564BNSR	SN74LS161ANSR	THS4031CDR	UCC2580D-4
OPA693ID	SN74ALS573CDB	SN74LS163ANS	THS4031ID	UCC2585D
OPA698ID	SN74ALS573CDBR	SN74LS163ANSR	THS4032CD	UCC27200D
OPA698IDG4	SN74ALS573CNS	SN74LS164NS	THS4032CDG4	UCC27200DR
OPA698IDR	SN74ALS573CNSR	SN74LS164NSR	THS4032ID	UCC27201AD
OPA698IDRG4	SN74ALS574BDB	SN74LS165ANS	THS4032IDR	UCC27201ADR
OPA699ID	SN74ALS574BNS	SN74LS165ANSR	THS4042CD	UCC27201D
OPA734AID	SN74ALS574BNSR	SN74LS166ANS	THS4051CD	UCC27201DR
OPA735AID	SN74ALS576BNS	SN74LS166ANSR	THS4051CDR	UCC28019AD
OPA875ID	SN74ALS576BNSR	SN74LS169BNS	THS4051ID	UCC28019ADR
PCA9536D	SN74ALS620ANS	SN74LS174NS	THS4051IDR	UCC28019D
PCA9536DG4	SN74ALS620ANSR	SN74LS174NSR	THS4051IDRG4	UCC28019DR
PCA9539DB	SN74ALS623ANS	SN74LS175NS	THS4052CD	UCC2803D
PCA9548ADB	SN74ALS623ANSR	SN74LS175NSR	THS4052CDR	UCC2803DG4
PCA9555DBR	SN74ALS638ANS	SN74LS191NS	THS4052CDRG4	UCC2803DTR
PCA9557DR	SN74ALS638ANSR	SN74LS191NSR	THS4052IDR	UCC2804DTR
PCF8575DBR	SN74ALS639ANSR	SN74LS193NS	THS4061CD	UCC28050D
PCM1725D	SN74ALS640B-1NS	SN74LS193NSR	THS4061CDG4	UCC28050DR
PCM1725DR	SN74ALS640B-1NSR	SN74LS19ANS	THS4061CDR	UCC28051D
PCM1725U	SN74ALS640BNS	SN74LS19ANSR	THS4061ID	UCC28051DR
PCM1725U/2K	SN74ALS640BNSR	SN74LS20NS	THS4061IDG4	UCC2805D
PCM1741E	SN74ALS640BNSRG4	SN74LS20NSR	THS4061IDR	UCC28060D
PCM1741E/2K	SN74ALS641A-1DB	SN74LS21NS	THS4062CDR	UCC28060DG4
PCM1741E/2KG4	SN74ALS641A-1DBR	SN74LS21NSR	THS4062ID	UCC28060DR
PCM1742E	SN74ALS641A-1NS	SN74LS221DB	THS4062IDR	UCC28061D
PCM1742KE	SN74ALS641A-1NSR	SN74LS221DBR	THS4081ID	UCC28061DR
PCM1742KE/2K	SN74ALS641ANS	SN74LS221NS	THS4081IDG4	UCC28063DR
PCM1742KE/2KG4	SN74ALS641ANSR	SN74LS221NSR	THS4082CD	UCC2806DTR
PCM1742KEG4	SN74ALS642A-1DB	SN74LS240DB	THS4082ID	UCC2807D-3
PCM1744U	SN74ALS642A-1NS	SN74LS240DBR	THS4130CDG4	UCC28084D
PCM1748E	SN74ALS642A-1NSR	SN74LS240NS	THS4130ID	UCC28084DR
PCM1748KE	SN74ALS645A-1DB	SN74LS240NSR	THS4131CD	UCC28089D
PCM1748KE/2K	SN74ALS645A-1NS	SN74LS241NS	THS4131CDR	UCC2808AD-2G4
PCM1748KE/2KG4	SN74ALS645A-1NSR	SN74LS241NSR	THS4131ID	UCC2808ADTR-2

日本テキサス・インスツルメンツ株式会社

PCM1751DBQR	SN74ALS645ANS	SN74LS244DB	THS4131IDR	UCC2809D-1
PCM1753DBQ	SN74ALS645ANSR	SN74LS244DBR	THS4150CDR	UCC2809DTR-1G4
PCM1753DBQR	SN74ALS688NS	SN74LS244DBRG4	THS4215D	UCC2813D-5
PCM1753DBQR-S2	SN74ALS688NSR	SN74LS244NS	THS4221D	UCC2813DTR-0G4
PCM1754DBQ	SN74ALS74ADB	SN74LS244NSR	THS4222D	UCC2813DTR-3G4
PCM1754DBQ-P	SN74ALS74ANS	SN74LS245DB	THS4222DR	UCC2813DTR-5
PCM1754DBQR	SN74ALS74ANSR	SN74LS245DBR	THS4271D	UCC2817ADR
PCM1755DBQ	SN74ALS86DB	SN74LS245DBRG4	THS4271DG4	UCC2818AD
PCM1780DBQ	SN74ALS86NS	SN74LS245NS	THS4271DR	UCC2818ADR
PCM1780DBQR	SN74ALS86NSR	SN74LS245NSR	THS4281D	UCC2818ADR/1
PCM1781DBQ	SN74ALVCO0NSR	SN74LS247NS	THS4304D	UCC2818DTR
PCM1781DBQR	SN74ALVCO4NS	SN74LS247NSR	THS4501CD	UCC2819AD
PCM1781DBQRG4	SN74ALVCO8NS	SN74LS251NS	THS4502CD	UCC2819ADR
PCM1795DB	SN74ALVCO8NSR	SN74LS251NSR	THS45021D	UCC2819ADRG4
PCM1795DBR	SN74ALVC125NS	SN74LS253NS	THS45031D	UCC2819DTR
PCM1801U	SN74ALVC125NSR	SN74LS253NSR	THS4504D	UCC28220D
PCM1801U/2K	SN74ALVC14DR	SN74LS257BNS	THS4504DG4	UCC28220DR
PCM1801U/2KG4	SN74ALVC14NSR	SN74LS257BNSR	THS4504DRG4	UCC2837D
PCM1801UG4	SN74ALVC164245DL	SN74LS259BNS	THS4601CD	UCC2837DTR
PCM1803DB	SN74ALVC164245DLR	SN74LS266NS	THS46011D	UCC284DP-5
PCM1803DBR	SN74ALVC244NS	SN74LS266NSR	THS4631D	UCC284DP-ADJ
PCM2704CDB	SN74ALVC245NS	SN74LS26NS	TIR1000IPSR	UCC284DP-ADJG4
PCM2704DB	SN74ALVC32D	SN74LS273NS	TIR1000PS	UCC28600D
PCM2704DBG4	SN74ALVC32NSR	SN74LS273NSR	TIR1000PSR	UCC28600DR
PCM2704DBR	SN74ALVCH16245DL	SN74LS279ANS	TL022CPS	UCC28610DR
PCM2705DB	SN74ALVCH16245DLR	SN74LS279ANSR	TL022CPSR	UCC28810D
PGA2500IDB	SN74ALVCH16374DLR	SN74LS27NS	TL026CPS	UCC28810DR
PGA2500IDBG4	SN74ALVCH16543DL	SN74LS27NSR	TL026CPSR	UCC2889D
PGA2500IDBR	SN74ALVCH16827DL	SN74LS280NS	TL032CPS	UCC2889DTRG4
PGA2500IDBRG4	SN74ALVCH245NSR	SN74LS280NSR	TL032CPSR	UCC2891D
PLL1705DBQ	SN74ALVTH162244DL	SN74LS283NSR	TL034CNS	UCC2891DG4
PLL1705DBQR	SN74ALVTH16244DL	SN74LS298NS	TL034CNSR	UCC2891DR
PLL1705S1DBQR	SN74ALVTH16244DLR	SN74LS30NS	TL052ACPS	UCC2894D
PLL1707DBQ	SN74ALVTH16245DL	SN74LS30NSR	TL052CPS	UCC28C40D
PLL1707DBQR	SN74ALVTH16245DLR	SN74LS31NS	TL052CPSR	UCC28C41D
PLL1708DBQ	SN74ALVTH16374DLR	SN74LS31NSR	TL054CNS	UCC28C41DR
PLL1708DBQR	SN74ALVTH16821DL	SN74LS32DB	TL054CNSR	UCC28C42D
RC4558DR	SN74ALVTH16821DLR	SN74LS32DBR	TL061CPS	UCC28C43D
RC4558PSR	SN74ALVTH16827DL	SN74LS32NS	TL061CPSR	UCC28C43DR
REG103UA-3.3	SN74AS00DB	SN74LS32NSR	TL062ACPS	UCC28C44D
REG103UA-5/2K5	SN74AS00DBR	SN74LS33NS	TL062ACPSR	UCC28C45D
REG103UA-A	SN74AS00NS	SN74LS33NSR	TL062CPS	UCC29002D
RI-RFM-006A-30	SN74AS00NSR	SN74LS348NS	TL062CPSR	UCC29002DR
SG3524NS	SN74AS02NS	SN74LS365ANS	TL062CPSRG4	UCC2917D
SG3524NSR	SN74AS02NSR	SN74LS365ANSR	TL064CDB	UCC2946D
SN0511065NS	SN74AS04DB	SN74LS367ANS	TL064CNS	UCC2946DTR
SN0511065NSR	SN74AS04DBR	SN74LS367ANSR	TL064CNSR	UCC35705D
SN0907036DR	SN74AS04NS	SN74LS368ANS	TL0641NSR	UCC3580D-3
SN1011013DR	SN74AS04NSR	SN74LS368ANSR	TL071CPS	UCC3800D
SN101178NSR	SN74AS08DB	SN74LS373NS	TL071CPSR	UCC3800DTR
SN104223NSR	SN74AS08DBR	SN74LS373NSR	TL072ACPS	UCC3801D
SN104800PSR	SN74AS08NS	SN74LS374DB	TL072ACPSR	UCC3801DTRG4
SN104801PSR	SN74AS08NSR	SN74LS374NS	TL072CPS	UCC3803DG4
SN104804D	SN74AS1000ANS	SN74LS374NSR	TL072CPS-P	UCC3803DTR
SN104804DR	SN74AS1000ANSR	SN74LS374NSRG4	TL072CPSR	UCC3803DTRG4
SN104806DR	SN74AS1004ANSR	SN74LS375NS	TL074ACNS	UCC3805DG4
SN10501D	SN74AS1034ANS	SN74LS375NSR	TL074ACNSR	UCC3805DTR/81199G4

日本テキサス・インスツルメンツ株式会社

SN10501DR	SN74AS109ANSR	SN74LS377NS	TL074CDBR	UCC3805DTR/81222G4
SN10502D	SN74AS10NSR	SN74LS377NSR	TL074CNS	UCC3805DTRG4
SN10502DR	SN74AS11NS	SN74LS378NS	TL074CNSR	UCC3807D-2
SN10503D	SN74AS11NSR	SN74LS37NS	TL074CNSRG4	UCC38084D
SN105239DBR	SN74AS138NS	SN74LS37NSR	TL080CPSR	UCC3808D-2
SN200505022DBR	SN74AS138NSR	SN74LS38240DBR	TL081CPS	UCC3809DTR-1
SN200707060DR	SN74AS151NS	SN74LS38244DBR	TL081CPSR	UCC3813DTR-0
SN250129NSR	SN74AS151NSR	SN74LS38DB	TL082ACPS	UCC3813DTR-0G4
SN28878DNS	SN74AS153NS	SN74LS38DBR	TL082ACPSR	UCC3813DTR-1
SN320002NSR	SN74AS153NSR	SN74LS38NS	TL082CPS	UCC3813DTR-1G4
SN64BCT125ANSR	SN74AS157NS	SN74LS38NSR	TL082CPSR	UCC3813DTR-3
SN64BCT126ANSR	SN74AS157NSR	SN74LS390NS	TL084ACNS	UCC3817AD
SN64BCT244NS	SN74AS158NSR	SN74LS390NSR	TL084ACNSR	UCC3817ADR
SN64BCT244NSR	SN74AS161NS	SN74LS390NSRE4	TL084CNS	UCC3817D
SN65ALS541ANSRG4	SN74AS161NSR	SN74LS393NS	TL084CNSR	UCC3817DG4
SN65ALS544ANSRG4	SN74AS163NS	SN74LS393NSR	TL092CPS	UCC3817DTR
SN65C1167ENS	SN74AS169ANS	SN74LS399NS	TL092CPSR	UCC3818ADR
SN65C1167ENSR	SN74AS174NS	SN74LS423NS	TL1451ACDBR	UCC3818D
SN65C1168ENS	SN74AS174NSR	SN74LS423NSR	TL1451ACDBRG4	UCC3818DTR
SN65C1168ENSR	SN74AS175BNS	SN74LS42NS	TL1451ACNS	UCC384DP-5
SN65C1168NS	SN74AS175BNSR	SN74LS47NS	TL1451ACNSR	UCC384DP-ADJ
SN65C1168NSR	SN74AS194NS	SN74LS47NSR	TL1451CDBR	UCC384DPTR-5
SN65C3221DB	SN74AS20DB	SN74LS51NSR	TL1451CNS	UCC384DPTR-5/1
SN65C3221DBR	SN74AS20NS	SN74LS540DB	TL1451CNSR	UCC384DPTR-ADJ
SN65C3221EDBR	SN74AS20NSR	SN74LS540DBR	TL1451INSR	UCC38C42DR
SN65CML100D	SN74AS21NS	SN74LS540NS	TL1453CNS	UCC38C43D
SN65HVD05D	SN74AS21NSR	SN74LS540NSE4	TL1453CNSR	UCC38C43DG4
SN65HVD05DR	SN74AS240ANS	SN74LS540NSR	TL1494CNSR	UCC38C43DR
SN65HVD06D	SN74AS240ANSR	SN74LS541DB	TL3016CD	UCC38C45DR
SN65HVD07D	SN74AS241ANS	SN74LS541DBR	TL3016CDG4	UCC39002D
SN65HVD07DR	SN74AS244ADB	SN74LS541DBRG4	TL3016CDR	UCC39002DR
SN65HVD07DRG4	SN74AS244ANS	SN74LS541NS	TL3016ID	UCC3918DP
SN65HVD08D	SN74AS244ANSR	SN74LS541NSR	TL3016IDG4	UCC3918DPTR
SN65HVD08DG4	SN74AS245DB	SN74LS541NSRG4	TL3016IDR	UCC3919DTR
SN65HVD08DR	SN74AS245NS	SN74LS590NS	TL3116ID	UCC3946D
SN65HVD08DRG4	SN74AS245NSR	SN74LS590NSR	TL3116IDG4	UCC5614DP
SN65HVD1040D	SN74AS253ANS	SN74LS592NS	TL3116IDR	ULN2003A1NSR
SN65HVD1040DR	SN74AS257NS	SN74LS592NSR	TL3116IDRG4	ULN2003ANS
SN65HVD1050D	SN74AS257NSR	SN74LS595NS	TL317PS	ULN2003ANS-P
SN65HVD1050DG4	SN74AS258NS	SN74LS596NS	TL317PSR	ULN2003ANSR
SN65HVD1050DR	SN74AS27NS	SN74LS597NS	TL431ACPS	ULN2003ANSRG4
SN65HVD1050DRG4	SN74AS27NSR	SN74LS623NS	TL431ACPSR	ULN2004A1NSR
SN65HVD10D	SN74AS280NS	SN74LS624NS	TL431BCPSR	ULN2004ANS
SN65HVD10DR	SN74AS280NSR	SN74LS624NSR	TL431CPS	ULN2004ANSR
SN65HVD10DRG4	SN74AS30DBR	SN74LS624NSRG4	TL431CPSR	VCA8211D
SN65HVD10QD	SN74AS30NS	SN74LS628NS	TL441CNS	VCA8221D
SN65HVD1176D	SN74AS30NSR	SN74LS628NSR	TL441CNSR	VCA8241D

日本テキサス・インスツルメンツ株式会社

信頼性試験

信頼性試験計画

信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	PCA9557D	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.96 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験計画

信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	TL598CDR	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	1.15 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験計画

信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	TPS2042BD	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/8	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	1.98 Mil Dia., Cu	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
Electrical Characterization	-	5	-	-
**High Temp. Storage Bake	170C, 420hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

日本テキサス・インスツルメンツ株式会社

信頼性試験計画				
信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	TPS2419DR	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/8	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.96 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**High Temp. Storage Bake	170C, 420hrs	77	77	77
**Biased HAST	130C/85%RH, 96 Hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	-	-
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験計画				
信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	SN65LVCP22DR	-	-	
Assembly Site:	TI Taiwan	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4042500	Mold Compound:	4211880	
Bond Wire:	0.96 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**High Temp. Storage Bake	170C, 420hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験計画				
信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	SN75976A1DL	-	-	
Assembly Site:	TI Malaysia	Package/Code/Pins:	SOIC/DL/56	
Mount Compound:	4042500	Mold Compound:	4211880	
Bond Wire:	0.96 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-2/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**High Temp. Storage Bake	170C,420hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-2/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-2/260C				

日本テキサス・インスツルメンツ株式会社

信頼性試験計画				
信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	TL1454ACDBR	-	-	
Assembly Site:	TI Malaysia	Package/Code/Pins:	SSOP/DB/16	
Mount Compound:	4042500	Mold Compound:	4211880	
Bond Wire:	0.80 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**High Temp. Storage Bake	170C, 420hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験計画				
信頼性試験期間	開始	2012 年 2 月	終了	2012 年 10 月
信頼性試験 - 試料構成詳細				
Qual Device:	TLC320AD77CDBR	-	-	
Assembly Site:	TI Malaysia	Package/Code/Pins:	SSOP/DB/28	
Mount Compound:	4042500	Mold Compound:	4211880	
Bond Wire:	1.2 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験計画				
Reliability Test	Condition / Duration	Sample Size		
		Lot#1	Lot#2	Lot#3
**High Temp. Storage Bake	170C, 420hrs	77	77	77
**Autoclave	121C, 96 Hrs	77	77	77
**T/C	-65C/150C, 500 Cycle	77	77	77
Manufacturability	per mfg. Site specification	per spec	per spec	per spec
Moisture Sensitivity	JEDEC L-1/260C	12	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信賴性試驗計畫				
信賴性試驗期間	開始	2012 年 2 月	終了	2012 年 10 月
信賴性試驗 — 試料構成詳細				
Qual Device:	TPA4860DR	-	-	
Assembly Site:	TI Taiwan	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4042500	Mold Compound:	4211880	
Bond Wire:	1.15 Mil Dia., Au	Lead frame (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信賴性試驗計畫				
Reliability Test	Condition / Duration		Sample Size	
**Autoclave	121C, 96 Hrs		77	
**T/C	-65C/150C, 500 Cycle		77	
Manufacturability	per mfg. Site specification		per spec	
Moisture Sensitivity	JEDEC L-1/260C		12	
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

日本テキサス・インスツルメンツ株式会社

信頼性試験結果				
信頼性試験期間	開始	—	終了	2011 年 10 月 17 日
信頼性試験 — 試料構成詳細				
Qual Device:	CD4053BM96		-	-
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.95 Mil Dia., Cu	Leadframe (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C		-	-
信頼性試験結果				
Reliability Test	Condition / Duration		Sample Size/ Fails	
Steady-state Life Test	150C, 168, 300 Hrs		77/0	
Electrical Characterization	-		Approved	
**High Temp. Storage Bake	170C, 420 Hrs		77/0	
**Biased HAST	130C/85%RH, 96 Hrs		77/0	
**Autoclave	121C, 96 Hrs		77/0	
**T/C	-65C/150C, 500 Cyc		77/0	
**Thermal Shock	-65C/150C, 500 Cyc		77/0	
Visual / Mechanical	-		Approved	
Lead Pull	# of leads to destruction, min. 3 units		22/0	
Bond Strength	76 ball bonds, min. 3 units		76/0	
X-ray	Top-side only		5/0	
Manufacturability	per mfg. Site specification		Approved	
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験結果				
信頼性試験期間	開始	—	終了	2011 年 10 月 17 日
信頼性試験 - 試料構成詳細				
Qual Device:	LM358DR	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/8	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.95 Mil Dia., Cu	Leadframe (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験結果				
Reliability Test	Condition / Duration	Sample Size/ Fails		
		Lot#1	Lot#2	Lot#3
Steady-state Life Test	150C, 168, 300 hrs	77/0	-	-
Electrical Characterization	-	Approved	-	-
**High Temp. Storage Bake	170C, 420 Hrs	77/0	-	-
**Biased HAST	130C/85%RH, 96 Hrs	77/0	-	-
**Autoclave	121C, 96 Hrs	77/0	-	-
**T/C	-65C/150C, 500 Cyc	77/0	77/0	77/0
**Thermal Shock	-65C/150C, 500 Cyc	77/0	77/0	77/0
Visual / Mechanical	-	Approved	-	-
Lead Pull	# of leads to destruction, min. 3 units	22/0	-	-
X-ray	top side only	5/0	-	-
Bond Strength	76 ball bonds, min. 3 units	76/0	-	-
Manufacturability	per mfg. Site specification	Approved	-	-
Moisture Sensitivity	JEDEC L-1/260C	12/0	12/0	12/0
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験結果				
信頼性試験期間	開始	—	終了	2011 年 10 月 17 日
信頼性試験 - 試料構成詳細				
Qual Device:	TL494IDR	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.95 Mil Dia., Cu	Leadframe (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験結果				
Reliability Test	Condition / Duration	Sample Size/ Fails		
		Lot#1	Lot#2	Lot#3
Steady-state Life Test	150C, 168, 300 hrs	77/0	77/0	77/0
Electrical Characterization	-	Approved	-	-
**High Temp. Storage Bake	170C, 420 Hrs	77/0	77/0	77/0
**Biased HAST	130C/85%RH, 96 Hrs	77/0	77/0	77/0
**Autoclave	121C, 96 Hrs	77/0	77/0	77/0
**T/C	-65C/150C, 500 Cyc	77/0	77/0	77/0
**Thermal Shock	-65C/150C, 500 Cyc	77/0	77/0	77/0
Visual / Mechanical	-	Approved	Approved	Approved
Lead Pull	# of leads to destruction, min. 3 units	22/0	22/0	22/0
Flammability	Method A - UL94V-0	5/0	5/0	5/0
Flammability	Method B - IEC 695-2-2	5/0	5/0	5/0
Flammability	Method C - UL1694	5/0	5/0	5/0
Bond Strength	76 ball bonds, min. 3 units	76/0	76/0	76/0
Manufacturability	per mfg. Site specification	Approved	Approved	Approved
X-ray	top side only	5/0	5/0	5/0
Moisture Sensitivity	JEDEC L-1/260C	12/0	12/0	12/0
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				

信頼性試験結果				
信頼性試験期間	開始	—	終了	2011 年 10 月 17 日
信頼性試験 - 試料構成詳細				
Qual Device:	ULN2003ADR	-	-	
Assembly Site:	TI Mexico	Package/Code/Pins:	SOIC/D/16	
Mount Compound:	4147858	Mold Compound:	4211880	
Bond Wire:	0.95 Mil Dia., Cu	Leadframe (Finish, Base):	NiPdAu, Cu	
MSL:	JEDEC L-1/260C	-	-	
信頼性試験結果				
Reliability Test	Condition / Duration	Sample Size/ Fails		
		Lot#1	Lot#2	Lot#3
Steady-state Life Test	150C, 168, 300 Hrs	77/0	-	-
Electrical Characterization	-	30/0	-	-
**High Temp. Storage Bake	150C, 500, 1000 Hrs	77/0	77/0	77/0
**Biased HAST	130C/85%RH, 96 Hrs	77/0	-	-
**Autoclave	121C, 96 Hrs	77/0	77/0	77/0
**T/C	-65C/150C, 500 Cyc	77/0	77/0	77/0
**Thermal Shock	-65C/150C, 500 Cyc	77/0	77/0	77/0
Lead Pull	# of leads to destruction, min. 3 units	22/0	22/0	22/0
Bond Strength	76 ball bonds, min. 3 units	76/0	-	-
Manufacturability	per mfg. Site specification	Approved	-	-
X-ray	Top-side only	5/0	5/0	5/0
Visual / Mechanical	-	Approved	-	-
Moisture Sensitivity	JEDEC L-1/260C	12/0	-	-
Notes: ** Preconditioning Sequence: JEDEC L-1/260C				